Solution User Guide

R5020

High Speed Smart 5G Router





Guangzhou Robustel LTD www.robustel.com



About This Document

This document provides hardware and software information of the Robustel R5020 Router, including introduction, installation, configuration and operation.

Copyright©2020 Guangzhou Robustel LTD All rights reserved.

Trademarks and Permissions

B CODUSTER CODUSTOS are trademark of Guangzhou Robustel LTD. All other trademarks and trade

names mentioned in this document are the property of their respective owners.

Disclaimer

No part of this document may be reproduced in any form without the written permission of the copyright owner. The contents of this document are subject to change without notice due to continued progress in methodology, design and manufacturing. Robustel shall have no liability for any error or damage of any kind resulting from the use of this document.

Technical Support SECTRON Tel: +420 599 509 599 Email: hotline@sectron.cz

Web: www.sectron.eu

RT_UG_R5020_v.1.0.0



Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the router is used in a normal manner with a well-constructed network, the router should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Robustel accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the router, or for failure of the router to transmit or receive such data.

Safety Precautions

General

- The router generates radio frequency (RF) power. When using the router, care must be taken on safety issues related to RF interference as well as regulations of RF equipment.
- Do not use your router in aircraft, hospitals, petrol stations or in places where using cellular products is prohibited.
- Be sure that the router will not be interfering with nearby equipment. For example: pacemakers or medical equipment. The antenna of the router should be away from computers, office equipment, home appliance, etc.
- An external antenna must be connected to the router for proper operation. Only uses approved antenna with the router. Please contact authorized distributor on finding an approved antenna.
- Always keep the antenna with minimum safety distance of 20 cm or more from human body. Do not put the antenna inside metallic box, containers, etc.
- RF exposure statements
 - 1. For mobile devices without co-location (the transmitting antenna is installed or located more than 20cm away from the body of user and nearby person)
- FCC RF Radiation Exposure Statement
 - 1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
 - 2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and human body.

Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Router may be used at this time.

Using the Router in Vehicle

- Check for any regulation or law authorizing the use of cellular devices in vehicle in your country before installing the router.
- The driver or operator of any vehicle should not operate the router while driving.
- Install the router by qualified personnel. Consult your vehicle distributor for any possible interference of electronic parts by the router.
- The router should be connected to the vehicle's supply system by using a fuse-protected terminal in the vehicle's fuse box.
- Be careful when the router is powered by the vehicle's main battery. The battery may be drained after extended period.

Protecting Your Router

To ensure error-free usage, please install and operate your router with care. Do remember the following:

• Do not expose the router to extreme conditions such as high humidity / rain, high temperature, direct sunlight,



caustic / harsh chemicals, dust, or water.

- Do not try to disassemble or modify the router. There is no user serviceable part inside and the warranty would be void.
- Do not drop, hit or shake the router. Do not use the router under extreme vibrating conditions.
- Do not pull the antenna or power supply cable. Attach/detach by holding the connector.
- Connect the router only according to the instruction manual. Failure to do it will void the warranty.
- In case of problem, please contact authorized distributor.



Regulatory and Type Approval Information

Table 1: Directives

2011/65/EU	The European RoHS2.0 2011/65/EU Directive was issued by the European parliament and the European Council on 1 July 2011 on the restriction of the use of certain Hazardous substances in electrical and electronic equipment.	ROH5 compliant
2012/19/EU	The European WEEE 2012/19/EU Directive was issued by the European parliament and the European Council on 24 July 2012 on waste electrical and electronic equipment.	X
2013/56/EU	The European 2013/56/EU Directive is a battery Directive which published in the EU official on 10 December 2013. The button battery used in this product conforms to the sta 2013/56/EU directive.	•

Table 2: Standards of the electronic industry of the People's Republic of China

	, , ,
SJ/T	The electronic industry standard of the People's Republic of China SJ/T 11363-2006 "Requirements
11363-2006	for Concentration Limits for Certain Toxic and Hazardous Substances in Electronic Information
	Products" issued by the ministry of information industry of the People's Republic of China on
	November 6, 2006, stipulates the maximum allowable concentration of toxic and hazardous
	substances in electronic information products.
	Please see Table 3 for an overview of toxic or hazardous substances or elements that might be
	contained in product parts in concentrations above the limits defined by SJ/T 11363-2006.
SJ/T	The electronic industry standard of the People's Republic of China SJ/T 11364-2014 "Labeling
11364-2014	Requirements for Restricted Use of Hazardous Substances in Electronic and Electrical Products"
	issued by the ministry of Industry and information technology of the People's Republic of China on
	July 9, 2014, stipulates the Labeling requirements of hazardous substances in electronic and
	electrical products, environmental protection use time limit and whether it can be recycled.
	This standard is applicable to electronic and electrical products sold within the territory of the
	People's Republic of China, and can also be used for reference in the logistics process of electronic
	and electrical products.
	The orange logo below is used for Robustel products:
	Indicates its warning attribute, that is, some hazardous substances are contained in the product.
	The "10" in the middle of the legend refers to the environment-friendly Use Period (EFUP) * of
	electronic information product, which is 10 years. It can be used safely during the
	environment-friendly Use Period. After the environmental protection period of use, it should enter
	the recycling system.
	*The term of environmental protection use of electronic information products refers to the term
	during which the toxic and hazardous substances or elements contained in electronic information
	products will not be leaked or mutated and cause serious pollution to the environment or serious
	damage to people and property under normal conditions of use.



Table 3: Toxic or Hazardous Substances or Elements with Defined Concentration Limits

Name of	Hazardo	Hazardous Substances								
the Part	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)	(DEHP)	(BBP)	(DBP)	(DIBP)
Metal parts	0	0	0	0	-	-	-	-	-	-
Circuit modules	0	0	0	0	0	0	0	0	0	0
Cables and cable assemblie s	0	0	0	0	0	0	0	0	0	0
Plastic and polymeric parts	0	0	0	0	0	0	0	0	0	0

o:

Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in RoHS2.0.

X:

Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials for this part *might exceed* the limit requirement in RoHS2.0.

-:

Indicates that it does not contain the toxic or hazardous substance.



Document History

Updates between document versions are cumulative. Therefore, the latest document version contains all updates made to previous versions.

Date	Firmware Version	Document Version	Change Description
Dec. 29, 2020	3.1.1	v.1.0.0	Initial release



Contents

Contents			8
Chapter 2	1	Product Overview	.10
1.1	I	Key Features	.10
1.2		Package Contents	.10
1.3	9	Specifications	.12
1.4	I	Dimensions	.14
Chapter 2	2	Hardware Installation	.15
2.1	I	Definition of 2*5 3.5mm Interface	.15
2.2	I	Definition of Power Interface	.16
2.3	I	LED Indicators	.16
2.4	I	USB Interface	.17
2.5	I	Reset Button	.18
2.6	I	Ethernet Ports	.18
2.7	I	nsert or Remove SIM Card	.19
2.8		Attach External Antenna (SMA Type)	.20
2.9		Mount the Router	.21
2.10) (Ground the Router	.23
2.11	L (Connect the Router to a Computer	.23
2.12	2	Power Supply	.24
2.13	8	DI/DO Interface	.26
Chapter 3	3	nitial Configuration	.29
3.1	(Configure the PC	.29
3.2		Factory Default Settings	.32
3.3	I	Log in the Router	.32
3.4	(Control Panel	.33
Chapter 4	4 I	nitial Configuration	.35
4.1		Status	.35
	4.1.1	System Information	.35
	4.1.2	Cellular Status	.35
	4.1.3	Internet Status	.36
4.2	I	nterface	.37
	4.2.1	Link Manager	.37
	4.2.2	LAN	.49
	4.2.3	Ethernet	.52
	4.2.4	Cellular	.54
	4.2.5	WiFi	.60
	4.2.6	USB	.72
	4.2.7	Z DI/DO	.73
	4.2.8	Serial Port	.78
4.3		Network	.82
	4.3.1		
	4.3.2	Firewall	.83

10 robustel

	4.3.3	IP Passthrough	
4.4	VF	PN	89
	4.4.1	IPsec	89
	4.4.2	OpenVPN	97
	4.4.3	GRE	109
4.5	Se	rvices	111
	4.5.1	Syslog	111
	4.5.2	Event	112
	4.5.3	NTP	115
	4.5.4	SMS	116
	4.5.5	Email	117
	4.5.6	DDNS	118
	4.5.7	SSH	119
	4.5.8	Ignition	120
	4.5.9	GPS	120
	4.5.10	Web Server	125
	4.5.11	Advanced	126
4.6	Sy	stem	127
	4.6.1	Debug	127
	4.6.2	Update	129
	4.6.3	App Center	129
	4.6.4	Tools	130
	4.6.5	Profile	132
	4.6.6	User Management	134
Chapter !	5 Co	onfiguration Examples	136
5.1	Ce	ellular	136
	5.1.1	Cellular Dial-Up	136
	5.1.2	SMS Remote Control	138
5.2	VF	PN Configuration Example	140
	5.2.1	IPsec VPN	140
	5.2.2	OpenVPN	144
	5.2.3	GRE VPN	146
Chapter (6 In	troductions for CLI	148
6.1	W	hat Is CLI	148
6.2	Нс	ow to Configure the CLI	149
6.3		ommands Reference	
6.4	Qı	uick Start with Configuration Examples	150
Glossary	•••••		159



Chapter 1 Product Overview

1.1 Key Features

Robustel R5020 dual-SIM VPN wireless router supports WCDMA 3G network, LTE 4G network, and 5G network to provide high-speed wireless network bandwidth for devices through wireless connection, and it has dual-SIM card backup to ensure stable wireless network connection.

R5020 adopts RobustOS, the operating system developed by Robustel, which is based on Linux and applicable to most of Robustel's router devices. Besides the basic network functions and protocols, the system brings customers a more diverse, convenient and practical customized experience. Also, Robustel will provide partners and customers with SDK, allowing users to develop their own functions using C language. In addition, Robustel will also provide rich App applications running on RobustOS to meet the fragmented market demand of IoT applications.

1.2 Package Contents

Before installing your R5020 Router, verify the kit contents as following. **Note**: The following pictures are for illustration purposes only, not based on their actual sizes.

• 1 x Robustel R5020 High Speed Smart LTE Router



• 1 x 3-pin 3.5 mm male terminal block with lock for power supply





• 1 x 2*5-pin 3.5 mm male terminal block for serial port



Note: If any of the above items is missing or damaged, please contact your Robustel sales representative.

Optional Accessories (sold separately)

• LTE-5G SMA-J cellular antenna (rubber antenna) Rubber antenna



RP-SMA-J WiFi antenna (stubby/magnet optional)
 Stubby antenna Magnet antenna





• RP-SMA-J GPS & 5G antenna



• Wall mounting kit





• 35 mm DIN rail mounting kit



• Ethernet cable



• AC/DC power adapter (12V DC, 1.5 A; EU/US/UK/AU plug optional)



1.3 Specifications

Cellular Interface

- Number of antennas: 4 (ANTO, ANT1/GNSS, ANT2/GNSS, ANT3)
- Connector: SMA-K
- SIM: 2 (3.0 V & 1.8 V)
- Standards: 5G NR/LTE-FDD/LTE-TDD/WCDMA
 5G: max UL/DL = 80/445 Mbps
 LTE-FDD: max UL/DL = 100/250 Mbps
 LTE-TDD: max UL/DL = 100/250 Mbps
 WCDMA: max UL/DL = 5.76/42 Mbps

Ethernet Interface

- Number of ports: 4 x 10/100/1000 Mbps (3 x LAN + 1 x WAN)
- WAN port: Supports 802.3at PD feature (optional) on ETH0
- Magnet isolation protection: 1 KV



WiFi Interface

- Number of antennas: 2 (WiFi1 + WiFi2)
- Connector: RP-SMA-K
- Standards: 802.11a/b/g/n/ac, 2*2 MIMO, supports AP and Client modes
 - Frequency bands: 2.412 2.472 GHz (2.4 GHz ISM band)
 - 5.15 5.825 GHz (5 GHz ISM band)
- Security: Open, WPA, WPA2, WEP
- Encryption: AES, TKIP, WEP64
- Data speed: 5G: Up to 867Mbps 2.4G: Up to 300Mbps

GPS (Optional)

- Number of antennas: 2 (ANT1/GNSS: L5, ANT2/GNSS: L1)
- Connector: SMA-K with 50 ohms impedance
- GNSS Technology: GPS, GLONASS, Galileo, BeiDou
- Tracking sensitivity: -160 dBm
- Horizontal position accuracy: 2.5 m

Serial Interface

- Number of ports: 1 x RS232 + 1 x RS485
- Connector: 2 x 5-pin 3.5 mm female socket
- ESD protection: ±15 KV
- Baud rate: 300 bps to 115200 bps
- Parameters: 8E1, 8O1, 8N1, 8N2, 8E2, 8O2, 7E2, 7O2, 7N2, 7E1, 7O1, 7N1
- RS232: TxD, RxD, GND
- RS485: Data+ (A), Data- (B)

DI/DO

- Type: 1 x DI + 1 x DO, wet contact
- Connector: 2 x 5-pin 3.5 mm female socket
- Isolation: 3.75KVDC
- Absolute maximum VDC: "V+" + 30VDC (DI), 30VDC (DO)
- Absolute maximum ADC: 100mA

Others

- 1 x RST button (Tact Switch)
- 1 x Micro SD interface
- 1 x USB 2.0 host, Type A, 5 V/500 mA
- LED indicators 1 x RUN, 1 x Modem, 1 x USR, 1 x RSSI, 1 x NET, 1 x WiFi Network port indicator (link indicator)
- Built-in: Watchdog, Timer

Power Supply and Consumption

- Connector: 3-pin 3.5 mm female socket with lock
- Input voltage: 10 to 30V DC (With ignition sensing)
 9 to 36V DC (Without ignition sensing)



Power consumption: Idle: 500 mA@12 V
 Data link: 1.5 A (peak) @12 V

Physical Characteristics

- Ingress protection: IP30
- Operating temperature: -25 ~ +70 °C
- Storage temperature: -40 ~ +85°C
- Humidity: 5 ~ 95% RH
- Housing & Weight: Aluminum, 500 g
- Dimensions: 125 x 100 x 48 mm (device only)
- Installations: Desktop, wall mounting or 35 mm DIN rail mounting (Wall mounting or 35 mm DIN rail mounting sold separately)

1.4 Dimensions





Chapter 2 Hardware Installation

2.1 Definition of 2*5 3.5mm Interface



PIN	DI/DO	RS-232	RS-485	Direction
1	IGND			
2	OGND			
3		TXD		Router \rightarrow Device
4		RXD		Router \leftarrow Device
5		GND		
6	IN			
7	OUT			
8			А	
9			В	
10			GND	



2.2 Definition of Power Interface



PIN	Power	Note
1	Positive	
2	Negative	
3	ACC	Car ignition and flameout detection

2.3 LED Indicators



Name	Color	Status	Description
RUN Green		On, solid	Router is powered on (System is initializing)
		On, blinking	Router starts operating
		Off	Router is powered off
MODEM	Green	On, solid	Link connection is working
		On, blinking	Data is sent and received.
		Off	Link connection is not working
NET	Green	On, solid	Connection to 4G network is established
		On, blinking	Connection to Legacy network (3G or 2G) is established
		Off	Network is not joined or joining
USR-OpenVPN	Green	On, solid	OpenVPN connection is established
		Off	OpenVPN connection is not established
USR-IPsec	Green	On, solid	IPsec connection is established
		Off	IPsec connection is not established



USR-SIM	Green	On, solid	Main SIM card is being used
		On, blinking	Backup SIM card is being used
		Off	No SIM card is being used
	Green	On, solid	Signal level: 21-30 dB (Strong signal)
	Yellow	On, solid	Signal level: 11-20 dB (Moderate signal)
	Red	On, solid	Signal level: 1-10 dB (Low signal)
		Off	Very Low Signal strength (0) is available or No signal
WiFi Green On, solid WiFi is enabled and working pr		WiFi is enabled and working properly	
		Off	WiFi is disabled or not working properly

Note: You can choose the display type of USR LED. For more details, please refer to Service > Advanced > System >System Settings > User LED Type.

2.4 USB Interface



Function	Operation
Firmware	USB interface is used for batch firmware upgrading, but cannot be used for sending or
upgrade	receiving data from slave devices which connected to it. You can insert a USB storage device
	into the router's USB interface, such as a U disk or a hard disk. If there have a supported
	configuration file or a router firmware in this USB storage device, the router will automatically
	update the configuration file or the firmware. For more details, see 4.2.6 USB .



2.5 Reset Button



Function	Operation
Reboot	Press and hold the RST button for at least 5 seconds under the operating status.
Restore to factory	Wait for 0~20 seconds after powering up the router, press and hold the RST button with a
default settings	pointed stick until all six LEDs start blinking one by one, and release the button to return the
	router to factory defaults.

2.6 Ethernet Ports



There are four Ethernet ports on R5020, including ETH0 (POE), ETH1, ETH2, ETH3. Each has two LED indicators. The yellow one is a link indicator but the green one doesn't mean anything. For details about status, see the table below.

Indicator	Status	Description
Link indicator	On, solid	Connection is established
(Yellow)	On, blinking	Data is being transferred
	Off	Connection is not established



2.7 Insert or Remove SIM Card



Insert or remove the SIM card as shown in the following steps.

• Insert SIM card

- 1. Make sure router is powered off.
- 2. To remove slot cover, loosen the screws associated with the cover by using a screwdriver and then find the SIM card slot.
- 3. To insert SIM card, press the card with finger until you hear a click and then tighten the screws associated with the cover by using a screwdriver.
- 4. To put back the cover and tighten the screws associated with the cover by using a screwdriver.

Remove SIM card

- 1. Make sure router is powered off.
- 2. To remove slot cover, loosen the screws associated with the cover by using a screwdriver and then find the SIM card slot.
- 3. To remove SIM card, press the card with finger until it pops out and then take out the card.
- 4. To put back the cover and tighten the screws associated with the cover by using a screwdriver.

Note:

1. Use the specific card when the device is working in extreme temperature (temperature exceeding 40 °C), because the regular card for long-time working in harsh environment will be disconnected frequently.



- 2. Do not forget to twist the cover tightly to avoid being stolen.
- 3. Do not touch the metal of the card surface in case information in the card will lose or be destroyed.
- 4. Do not bend or scratch the card.
- 5. Keep the card away from electricity and magnetism.
- 6. Make sure router is powered off before inserting or removing the card.

2.8 Attach External Antenna (SMA Type)

Attach an external SMA antenna to the router's antenna connector and twist tightly. Make sure the antenna is within the correct frequency range provided by the ISP and with 50 Ohm impedance. **Note:** Recommended torque for tightening is 0.35 N.m.





2.9 Mount the Router

The router can be placed on a desktop or mounted to a wall or a 35 mm DIN rail.

Two methods for mounting the router

1. Wall mounting (measured in mm)



Use 4 pcs of M2.5*4 flat head Phillips screws to fix the wall mounting kit to the router, and then use 2 pcs of M3 drywall screws to mount the router associated with the wall mounting kit on the wall. **Note:** Recommended torque for mounting is 1.0 N.m, and the maximum allowed is 1.2 N.m.

- 2. DIN rail mounting (measured in mm)
 - Option 1



Option 2

•





Use 2 pcs of M3*6 stainless flat head Phillips screws to fix the DIN rail to the router, and then hang the DIN rail on the mounting bracket. It is necessary to choose a standard bracket.

Note: Recommended torque for mounting is 1.0 N.m, and the maximum allowed is 1.2 N.m.

Solution of the second second

Use 2 pcs of M3*6 stainless flat head Phillips screws to fix the DIN rail to the router, and then hang the DIN rail on the mounting bracket. It is necessary to choose a standard bracket.

Note: Recommended torque for mounting is 1.0 N.m, and the maximum allowed is 1.2 N.m.



2.10 Ground the Router



Router grounding helps prevent the noise effect due to electromagnetic interference (EMI). Connect the router to the site ground wire by the ground screw before powering on.

Note: This product is appropriate to be mounted on a sound grounded device surface, such as a metal panel.

2.11 Connect the Router to a Computer



Connect an Ethernet cable to the port marked ETH1~ETH3 at the front of the R5020 Router, and connect the other end of the cable to your computer.



2.12 Power Supply

With Ignition Sensing



PIN	Description	Note
1	V+	Connect adapter or battery positive (red line)
2	V-	Connect adapter or battery negative (black)
3	ACC	Car ignition and flameout detection (green line), when the car ignition and flameout detection function is not used, the ACC pin is connected to the power supply and cannot be left floating.



With POE Function



PIN	Description	Note
1	V+	Connect adapter or battery positive (red line)
2	V-	Connect adapter or battery negative (black)
3	Not	
5	connected	

Note:

1. The Input voltage is: 10 to 30V DC(With ignition sensing)

9 to 36V DC (Without ignition sensing)

2. The car ignition sensing function and the POE function can only be selected one by one.



2.13 DI/DO Interface



The R5020 supports 1 channel DI and 1 channel DO by default. It can support 2 channels of DI or 2 channels of DO by BOM modification. DI signal access, can be used for NPN/PNP type sensor signal or switch signal acquisition, power supply can only be accessed from IN, not reversed. DO signal output, can be used for NPN/PNP sensor control. 1. Application mode of DI connected with NPN sensor



IN corresponds to IN on 2*5 3.5mm interface, and IGND corresponds to IGND on 2*5 3.5mm interface. The voltage range of external power supply (DC) is 3V ~ 30V. The internal flow of the device is limited. In the normal voltage range, the external power supply does not need to be limited.

Notes: The above example NPN Sensor is a DC three-wire NPN photoelectric switch or proximity switch.



2. Application mode of DI connected with PNP sensor



IN corresponds to IN on 2*5 3.5mm interface, and IGND corresponds to IGND on 2*5 3.5mm interface. The voltage range of external power supply (DC) is 3V ~ 30V; the internal flow of the device is limited. In the normal voltage range, the external power supply does not need to be limited.

Notes: The above example PNP Sensor is a DC three-wire NPN photoelectric switch or proximity switch.

3. Application mode of DO Driven NPN Triode



OUT corresponds to OUT on 2*5 3.5mm interface, and OGND corresponds to OGND on 2*5 3.5mm interface. The maximum 2.5mA drive current can be supplied through OGND; the external power supply DC voltage range is $3V^{3}OV$.

Notes: The above illustration NPN is a common NPN triode.

4. Application mode of DO Driven PNP Triode



OUT corresponds to OUT on 2*5 3.5mm interface, and OGND corresponds to OGND on 2*5 3.5mm interface. The



external power supply DC voltage range is 3V~30V. Notes: The above illustration PNP is a common NPN triode.



Chapter 3 Initial Configuration

The router can be configured through your web browser that including IE 8.0 or above, Chrome and Firefox, etc. A web browser is included as a standard application in the following operating systems: Linux, Mac OS, Windows 98/NT/2000/XP/Me/Vista/7/8, etc. There are various ways to connect the router, either through an external repeater/hub or connect directly to your PC. When the router is directly connected to the Ethernet port of the computer, if the router acts as a DHCP server, then the computer can get the IP directly from the router; the computer can also set a static IP in the same network segment as the router, so that the computer and the router form a small LAN. After the computer and the router have successfully established a connection, enter the default login address of the device on the computer's browser to enter the router's WEB login interface.

3.1 Configure the PC

There are two methods to get IP address for the PC. One is to obtain an IP address automatically from "Local Area Connection", and another is to configure a static IP address manually within the same subnet of the router. Please refer to the steps below.

Here take **Windows 7** as example, and the configuration for windows system is similar.

1. Click Start > Control panel, double-click Network and Sharing Center, and then double-click Local Area Connection.





2. Click **Properties** in the window of **Local Area Connection Status**.

🎚 Local Area Conr	nection Status	×
General		
Connection		
IPv4 Connectiv	vity:	Internet
IPv6 Connectiv	vity:	No Internet access
Media State:		Enabled
Duration:		09:30:11
Speed:		100.0 Mbps
Details)	
Activity ———		
	Sent — 툊	Received
Bytes:	12,818,574	83,948,334
Properties	🔞 Disable 🛛 Dia	agnose
		Close

3. Choose Internet Protocol Version 4 (TCP/IPv4) and click Properties.

🖞 Local Area Connection Properties			
Networking			
Connect using:			
Qualcomm Atheros AR8162/8166/8168 PCI-E Fast Etherr			
Configure			
This connection uses the following items:			
🗹 🔺 Link-Layer Topology Discovery Responder			
Install Uninstall Properties			
Description Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.			
OK Cancel			



4. Two ways for configuring the IP address of PC

Obtain an IP address automatically from the DHCP server and click "Obtain an IP address automatically";

General Alternate Configuration				
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.				
Obtain an IP address automatic	ally			
- Use the following IP address: -				
IP address:				
Subnet mask:				
Default gateway:				
Obtain DNS server address auto	omatically			
Obtain DNS server address addre				
Preferred DNS server:				
Alternate DNS server:				
Validate settings upon exit			Adva	nced

Use the following IP address:

(Configured a static IP address manually within the same subnet of the router. Click and configure "Use the following IP address.)

Internet Protocol Version 4 (TCP/IPv4) I	Properties
General	
You can get IP settings assigned autom this capability. Otherwise, you need to for the appropriate IP settings.	
Obtain an IP address automatical	у
Use the following IP address:	
IP address:	192 . 168 . 0 . 2
Subnet mask:	255 . 255 . 255 . 0
Default gateway:	192.168.0.1
Obtain DNS server address autom	natically
Use the following DNS server addr	resses:
Preferred DNS server:	192 . 168 . 0 . 1
Alternate DNS server:	• • •
Validate settings upon exit	Ad <u>v</u> anced
	OK Cancel

5. Click **OK** to finish the configuration.



3.2 Factory Default Settings

Item	Description
Username	admin
Password	admin
ETH0/POE	192.168.0.1/255.255.255.0, WAN mode
ETH1	192.168.0.1/255.255.255.0, LAN mode
ETH2	192.168.0.1/255.255.255.0, LAN mode
ETH3	192.168.0.1/255.255.255.0, LAN mode
DHCP Server	Enabled

Before configuring your router, you need to know the following default settings.

3.3 Log in the Router

To log in to the management page and view the configuration status of your router, please follow the steps below.

- 1. On your PC, open a web browser such as Internet Explorer, Google and Firebox, etc.
- 2. From your web browser, type the IP address of the router into the address bar and press enter. The default IP address of the router is <u>192.168.0.1</u>, though the actual address may vary.



3. In the login page, enter the username and password, choose language and then click **LOGIN**. The default username and password are "admin".

Note: If enter the wrong username or password over six times, the login web will be locked for 5 minutes.

B	robustel	
	Enter Username	
l	Enter Password	
	English 🗸	
	LOGIN	



3.4 Control Panel

	Status	
Status	∧ System Information	
Interface	Device Model	R5020-5G
Network	System Uptime	0 days, 00:01:51
VPN	System Time	Sun Jan 1 00:01:15 2017 (NTP not updated)
	RAM Usage	387M Free/448M Total
Services	Firmware Version	3.1.1 (Rev 3658)
System	Hardware Version	1.0.2
	Kernel Version	3.18.92
	Serial Number	
	∧ Internet Status	
	Active Link	
	Uptime	
	IP Address	
	Gateway	
	DNS	
	∧ LAN Status	
	IP Address	192.168.0.1/255.255.255.0
	MAC Address	34:FA:40:18:6E:FA
	Copyright © 2020 Robustel Technologies.	All rights reserved.

After logging in, the home page of the R5020 Router's web interface is displayed, for example.

In the home page, users can perform operations such as saving the configuration, restarting the router, and logging out.

Using the original password to log in the router, the page will pop up the following tab

 ${ig \Delta}$ It is strongly recommended to change the default password.

Click the *symbol* to close the popup. It is strongly recommended for security purposes that you change the default

username and/or password. To change your username and/or password, see **4.6.6 User Management**.

Control Panel			
Item	Description	Button	
Save & Apply	Click to save the current configuration into router's flash and apply the modification on every configuration page, to make the modification	Save & Apply	

×



	taking effect.	
Reboot	Click to reboot the router. If the Reboot button is yellow, it means that	Reboot
	some completed configurations will take effect only after reboot.	
Logout	Click to log the current user out safely. After logging out, it will switch to	Logout
	login page. Shut down web page directly without logout, the next one can	
	login web on this browser without a password before timeout.	
Submit	Click to save the modification on current configuration page.	Submit
Cancel	Click to cancel the modification on current configuration page.	Cancel

Note: The steps of how to modify configuration are as bellow:

- 1. Modify in one page;
- 2. Click Submit under this page;
- 3. Modify in another page;
- 4. Click **Submit** under this page;
- 5. Complete all modification;
- 6. Click Save & Apply



Chapter 4 Initial Configuration

4.1 Status

This page allows you to view the system information, internet status and LAN status of your router.

4.1.1 System Information

This section shows the system status information of your router.

∧ System Information	
Device Model	R5020-5G
System Uptime	0 days, 00:01:51
System Time	Sun Jan 1 00:01:15 2017 (NTP not updated)
RAM Usage	387M Free/448M Total
Firmware Version	3.1.1 (Rev 3658)
Hardware Version	1.0.2
Kernel Version	3.18.92
Serial Number	

System Information		
Item	Description	
Device Model	Show the model name of your device.	
System Uptime	Show the current amount of time the router has been connected.	
System Time	Show the current system time.	
RAM Usage	Show the free memory and the total memory.	
Firmware Version	Show the firmware version running on the router.	
Hardware Version	Show the current hardware version.	
Kernel Version	Show the current kernel version.	
Serial Number	Show the serial number of your device.	

4.1.2 Cellular Status

This section shows the cellular status information of the router.



∧ Internet Status	
Active Link	WWAN1
Uptime	0 days, 00:39:31
IP Address	10.122.74.11/255.255.255.248
Gateway	10.122.74.9
DNS	210.21.4.130 221.5.88.88

Cellular Status		
Item	Description	
Active Link	Show the current active link. WWAN1, WWAN2 or WAN.	
Uptime	Show the current amount of time the link has been connected.	
IP Address	Show the IP address of current link.	
Router	Show the router address of the current link.	
DNS	Show the current primary DNS server and secondary server.	

4.1.3 Internet Status

This section shows the Internet status information of the router.

∧ LAN Status	
IP Address	192.168.0.1/255.255.255.0
MAC Address	34:FA:40:18:6E:FA

Internet Status		
Item	Description	
IP Address	Show the IP address and the Netmask of the router.	
MAC Address	Show the MAC address of the router.	


4.2 Interface

4.2.1 Link Manager

This section allows you to setup the link connection. Link management is a network link backup feature that provides backup of mobile networks and Ethernet links.

Link Manager	Status	
∧ General Settin	igs	
	Primary Lin	WWAN1 🤍 🍞
	Backup Lin	WWAN2 V
	Backup Mode	Cold Backup 🧹 🍞
	Revert Interva	I 0 🦻
	Emergency Reboo	t ON OFF ?

	General Settings @ Link Manager	
Item	Description	Default
Primary Link	Select from "WWAN1", "WWAN2", "WAN" or "WLAN".	WWAN1
	WWAN1: Select SIM1 as the primary wireless link	
	WWAN2: Select SIM2 as the primary wireless link	
	WAN: Select WAN as the primary wired link	
	WLAN: Select WLAN as the primary wireless link	
	Note: WLAN link is available only if enable WiFi as Client mode, please	
	refer to 4.2.5 Interface > WiFi (Optional).	
Backup Link	Select from "None", "WWAN1", "WWAN2", "WAN", "WLAN" or "None".	WWAN2
	WWAN1: Select SIM1 as backup wireless link	
	WWAN2: Select SIM2 as backup wireless link	
	WAN: Select WAN as the backup wired link	
	WLAN: Select to make WLAN as the backup wireless link	
	Note: WLAN link is available only if enable WiFi as Client mode, please	
	refer to 4.2.5 Interface > WiFi (Optional).	
	None: Do not select any backup link	
Backup Mode	Select from "Cold Backup", "Warm Backup" or "Load Balancing".	Cold
	Cold Backup: The inactive link is offline on standby	Backup
	Warm Backup: The inactive link is online on standby	
	Note: Warm backup mode is not available for dual SIM backup.	
	Load Balancing: Use two links simultaneously	
Revert Interval	Specify the number of minutes that elapses before the primary link is	0
	checked if a backup link is being used in cold backup mode. 0 means disable	
	checking.	
	Note: Revert interval is available only under the cold backup mode.	
Emergency Reboot	Click the toggle button to enable/disable this option. Enable to reboot the	OFF
	whole system if no links available.	



Link Settings allows you to configure the parameters of link connection, including WWAN1/WWAN2, WAN and WLAN. It is recommended to enable Ping detection to keep the router always online. The Ping detection increases the reliability and also costs the data traffic.

∧ Link S	ettings			
Index	Туре	Description	Connection Type	
1	WWAN1		DHCP	
2	WWAN2		DHCP	
3	WAN		DHCP	
4	WLAN		DHCP	

Click Con the right-most of WWAN1/WWAN2 to enter the configuration window.

WWAN1/WWAN2

Link Manager	
∧ General Settings	
Index	1
Туре	WWAN1 V
Description	

The window is displayed as below when enabling the "Automatic APN Selection" option.

∧ WWAN Settings	
Automatic APN Selection	ON OFF
Dialup Number	*99***1#
Authentication Type	Auto
Switch SIM By Data Allowance	ON OFF ?
Data Allowance	0 7
Billing Day	1 🦻



The window is displayed as below when disabling the "Automatic APN Selection" option.

∧ WWAN Settings	
Automatic APN Selection	OFF
APN	internet
Username	
Password	
Dialup Number	*99***1#
Authentication Type	Auto
Switch SIM By Data Allowance	ON OFF ?
Data Allowance	
Billing Day	
A Ping Detection Settings	0
Enable	ON OFF
Primary Server	8.8.8.8
Secondary Server	114.114.114
Interval	300
Retry Interval	5
Timeout	3
Max Ping Tries	3
 Advanced Settings 	
NAT Enable	
Upload Bandwidth	
Download Bandwidth	
Overrided Primary DNS	
Overrided Secondary DNS	
Debug Enable	ON OFF
Verbose Debug Enable	OM OFF

Link Settings (WWAN)		
Item	Description	Default
General Settings		
Index	Indicate the ordinal of the list.	
Туре	Show the type of the link.	WWAN1
Description	Enter a description for this link.	Null
WWAN Settings		



	Link Settings (WWAN)	
Item	Description	Default
Automatic APN	Click the toggle button to enable/disable the "Automatic APN Selection"	ON
Selection	option. After enabling, the device will recognize the access point name	
	automatically. Alternatively, you can disable this option and manually add	
	the access point name.	
APN	Enter the Access Point Name for cellular dial-up connection, provided by	internet
	local ISP.	
Username	Enter the username for cellular dial-up connection, provided by local ISP.	Null
Password	Enter the password for cellular dial-up connection, provided by local ISP.	Null
Dialup Number	Enter the dialup number for cellular dial-up connection, provided by local ISP.	*99***1#
Authentication Type	Select from "Auto", "PAP" or "CHAP" as the local ISP required.	Auto
Switch SIM By Data	Click the toggle button to enable/disable this option. After enabling, it will	OFF
Allowance	switch to another SIM when the data limit reached.	
Anowance	Note: Only used for dual SIM backup.	
Data Allowance	Set the monthly data traffic limitation. The system will record the data	0
Data Anowance	traffic statistics when data traffic limitation (MiB) is specified. The traffic	Ū
	record will be displayed in Interface > Link Manager > Status > WWAN	
	Data Usage Statistics . 0 means disable data traffic record.	
Billing Day	Specify the monthly billing day. The data traffic statistics will be	1
89	recalculated from that day.	_
	Ping Detection Settings	
Enable	Click the toggle button to enable/disable the ping detection mechanism, a	ON
	keep-alive policy of the router.	
Primary Server	Router will ping this primary address/domain name to check that if the	8.8.8.8
	current connectivity is active.	
Secondary Server	Router will ping this secondary address/domain name to check that if the	114.114.11
becondury berver	current connectivity is active.	4.114
Interval	Set the ping interval.	300
Retry Interval	Set the ping retry interval. When ping failed, the router will ping again	5
	every retry interval.	
Timeout	Set the ping timeout.	3
Max Ping Tries	Set the max ping tries. Switch to another link or take emergency action if	3
	the max continuous ping tries reached.	
	Advanced Settings	1
NAT Enable	Click the toggle button to enable/disable the Network Address Translation	ON
	option.	
Upload Bandwidth	Set the upload bandwidth used for QoS, measured in kbps.	10000
Download Bandwidth	Set the download bandwidth used for QoS, measured in kbps.	10000
Overrided Primary DNS	Override primary DNS will override the automatically obtained DNS.	Null
Overrided Secondary DNS	Override secondary DNS will override the automatically obtained DNS.	Null



Link Settings (WWAN)		
Item	Description	Default
Debug Enable	Click the toggle button to enable/disable this option. Enable for debugging information output.	ON
Verbose Debug Enable	Click the toggle button to enable/disable this option. Enable for verbose debugging information output.	OFF



WAN

Router will obtain IP automatically from DHCP server if choosing "DHCP" as connection type. The window is displayed as below.

Link Manager	
∧ General Settings	
Index	3
Туре	WAN
Description	
Connection Type	DHCP

The window is displayed as below when choosing "Static" as the connection type.

∧ General Settings		
Index	3	
Туре	WAN	
Description		
Connection Type	Static v	
∧ Static Address Settings		
∧ Static Address Settings IP Address		
IP Address		

The window is displayed as below when choosing "PPPoE" as the connection type.

∧ General Settings	
Index	3
Туре	WAN
Description	
Connection Type	PPPoE
∧ WAN Settings	
Data Allowanc	e 0 🦻
Billing Da	y 1



∧ PPPoE Settings		
Username		
Password)
Authentication Type	Auto v	
PPP Expert Options) 🤊
∧ Ping Detection Settings		?
Enable	ON OFF	
Primary Server	8.8.8.8)
Secondary Server	114.114.114.114)
Interval	300) 🦻
Retry Interval	5) 🤊
Timeout	3) 🤊
Max Ping Tries	3) 🤊
Advanced Settings		
NAT Enable	ON OFF	
мти	1500)
Upload Bandwidth	10000	0
Download Bandwidth	10000)
Overrided Primary DNS)
Overrided Secondary DNS)

Debug Enable

Verbose Debug Enable

ON

OFF

Link Settings (WAN)				
Item	Description			
General Settings				
Index	Indicate the ordinal of the list.			
Туре	Show the type of the link.	WAN		
Description Enter a description for this link. Null				
Connection Type	Select from "DHCP", "Static" or "PPPoE".	DHCP		
Static Address Settings				
IP Address	Set the IP address with Netmask which can access the internet.	Null		
IP address with Netmask, e.g. 192.168.1.1/24				
Router Set the router of the IP address in WAN port. Null		Null		
Primary DNS Set the primary DNS. Null		Null		
Secondary DNS Set the secondary DNS. Null				
PPPoE Settings				



Username	Enter the username provided by your Internet Service Provider.	Null	
Password	Enter the password provided by your Internet Service Provider.	Null	
Authentication Type	Select from "Auto", "PAP" or "CHAP" as the local ISP required.	Auto	
PPP Expert Options	Enter the PPP Expert options used for PPPoE dialup. You can enter some Null		
	other PPP dial strings in this field. Each string can be separated by a		
	semicolon.		
	WAN Settings		
Data Allowance	Set the monthly data traffic limitation. The system will record the data	OFF	
	traffic statistics when data traffic limitation (MiB) is specified. The traffic		
	record will be displayed in Interface > Link Manager > Status > WWAN		
	Data Usage Statistics. 0 means disable data traffic record.		
Billing Day	Specify the monthly billing day. The data traffic statistics will be	1	
	recalculated from that day.		
	Ping Detection Settings		
Enable	Click the toggle button to enable/disable the ping detection mechanism, a	ON	
	keep-alive policy of the router.		
Primary Server	Router will ping this primary address/domain name to check that if the	8.8.8.8	
	current connectivity is active.		
Secondary Server	Router will ping this secondary address/domain name to check that if the	114.114.1	
	current connectivity is active.	14.114	
Interval	Set the ping interval.	300	
Retry Interval	Set the ping retry interval. When ping failed, the router will ping again	5	
	every retry interval.		
Timeout	Set the ping timeout.	3	
Max Ping Tries	Set the max ping tries. Switch to another link or take emergency action if	3	
	the max continuous ping tries reached.		
	Advanced Settings		
NAT Enable	Click the toggle button to enable/disable the Network Address Translation	ON	
	option.		
MTU	Enter the Maximum Transmission Unit.	1500	
Upload Bandwidth	Enter the upload bandwidth used for QoS, measured in kbps.	10000	
Download Bandwidth	Enter the download bandwidth used for QoS, measured in kbps.	10000	
Overrided Primary DNS	Override primary DNS will override the automatically obtained DNS.	Null	
Overrided Secondary	Override secondary DNS will override the automatically obtained DNS.	Null	
DNS			
Debug Enable	Click the toggle button to enable/disable this option. Enable for debugging	ON	
	information output.		
Verbose Debug Enable	Click the toggle button to enable/disable this option. Enable for verbose	OFF	
	debugging information output.		

WLAN

Router will obtain IP automatically from the WLAN AP if choosing "DHCP" as the connection type. The specific parameter configuration of SSID is shown as below.



Link Manager		
∧ General Settings		
	Index	4
	Туре	WLAN
	Description	
	Connection Type	DHCP
∧ WLAN Settings		
	SSID	Robustel
Connect to Hidden SSID		ON OFF
Password		•••••

The window is displayed as below when choosing "Static" as the connection type.

∧ General Settings			
	Index	4	
	Туре	WLAN	
	Description		
	Connection Type	Static v	
✓ WLAN Settings			
 Static Address Settings 			
	IP Address		0
	Gateway		
	Primary DNS		
	Secondary DNS		

R5020 does not support the **PPPoE** WLAN Connection Type.

∧ Ping Detection Settings	0
Enable	ON OFF
Primary Server	8.8.8.8
Secondary Server	114.114.114
Interval	300
Retry Interval	5 🧿
Timeout	3
Max Ping Tries	3



Advanced Settings	
NAT Enable	ON OFF
МТО	1500
Upload Bandwidth	10000 7
Download Bandwidth	10000
Overrided Primary DNS	
Overrided Secondary DNS	
Debug Enable	ON OFF
Verbose Debug Enable	ON OFF

	Link Settings (WLAN)				
Item	Item Description				
General Settings					
Index Indicate the ordinal of the list.					
Туре	Show the type of the link.	WLAN			
Description	Enter a description for this link.	Null			
Connection Type	Select from "DHCP" or "Static".	DHCP			
	WLAN Settings				
SSID	Enter a 1-32 characters SSID which your router wants to connect. SSID	router			
	(Service Set Identifier) is the name of your wireless network.				
Connect to Hidden SSID	Click the toggle button to enable/disable this option. When router works	OFF			
	as Client mode and needs to connect any access point which has hidden				
	SSID, you need to enable this option.				
Password	Enter an 8-63 characters password of the access point which your router	Null			
wants to connect.					
	Static Address Settings				
IP Address	Enter the IP address with Netmask which can access the Internet,	Null			
	e.g. 192.168.1.1/24				
Router	Enter the IP address of WiFi AP.	Null			
Primary DNS	Set the primary DNS.	Null			
Secondary DNS	Set the secondary DNS.	Null			
	Ping Detection Settings				
Enable	Click the toggle button to enable/disable the ping detection mechanism, a	ON			
	keepalive policy of the router.				
Primary Server	Router will ping this primary address/domain name to check that if the	8.8.8.8			
	current connectivity is active.				
Secondary Server	Router will ping this secondary address/domain name to check that if the	114.114.1			
	current connectivity is active.	14.114			
Interval	Set the ping interval.	300			
Retry Interval	Set the ping retry interval. When ping failed, the router will ping again	5			
	every retry interval.				
Timeout	Set the ping timeout.	3			

Max Ping Tries	Set the max ping tries. Switch to another link or take emergency action if		
	the max continuous ping tries reached.		
	Advance Settings		
NAT Enable	Click the toggle button to enable/disable the Network Address Translation	ON	
	option.		
MTU	Enter the Maximum Transmission Unit.	1500	
Upload Bandwidth	Enter the upload bandwidth used for QoS, measured in kbps.	10000	
Download Bandwidth	Enter the download bandwidth used for QoS, measured in kbps.	10000	
Overrided Primary DNS	Override primary DNS will override the automatically obtained DNS.	Null	
Overrided Secondary	Override secondary DNS will override the automatically obtained DNS.	Null	
DNS			
Debug Enable	Click the toggle button to enable/disable this option. Enable for debugging	ON	
	information output.		
Verbose Debug Enable	Click the toggle button to enable/disable this option. Enable for verbose	OFF	
	debugging information output.		

Status

This page allows you to view the status of link connection and clear the monthly data usage statistics.

Link Man	ager	Status			
∧ Link St	tatus				•••
Index	Link	Status	Uptime	IP Address	
1	WWAN1	Connected	0 days, 01:45:51	10.29.150.250/255.255.255.252	
2	WWAN2	Disconnected			

Click the right-most button •••• to select the connection status of the current link.



Brobustel



Click the row of the link, and it will show the details information of the current link connection under the row.

Link Man	ager	Status				
∧ Link St	atus					•••
Index	Link	Status	Uptin	ne	IP Address	
1	WWAN1	Connected	0 days, 01	:45:51	10.29.150.250/255.255.255.252	
			Index	1		
			Link	WWAN1		
			Status	Connected	1	
			Interface	wwan		
			Uptime	Uptime 0 days, 01:45:51		
			IP Address	Address 10.29.150.250/255.255.252		
			Gateway	Gateway 10.29.150.249		
			DNS	NS 202.96.134.33 202.96.128.166		
			RX Packets	s 17747		
			TX Packets	ts 10889		
			RX Bytes	Bytes 17716161		
			TX Bytes	2308800		
2	WWAN2	Disconnected				

∧ WWAN Data Usage Statistics	0
WWAN1 Monthly Stats	Clear
WWAN2 Monthly Stats	Clear
∧ WAN Data Usage Statistics	0
WAN Monthly Stats	Clear

Click the **Clear** button to clear SIM1 or SIM2 monthly data traffic usage statistics. Data statistics will be displayed

only if enable the Data Allowance function in Interface > Link Manager > Link Settings > WWAN Settings > Data Allowance.

∧ WWAN Settings	
Automatic APN Selection	ON OFF
Dialup Number	*99***1#
Authentication Type	Auto
Switch SIM By Data Allowance	ON OFF 7
Data Allowance	0 7
Billing Day	
∧ WAN Settings	
Data Allowance	0 0
Billing Day	

configuration of the LAN port.

Note: Lan0 cannot be deleted.

LAN	
∧ General Settings	
Index	1
Interface	lan0 v
IP Address	192.168.0.1
Netmask	255.255.255.0
МТ	1500

General Settings @ LAN				
ltem	Item Description			
Index	Indicate the ordinal of the list.			
Interface	Show the editing port.	lan0		
	Note: Lan1 is available only if it was selected by one of ETH1~ETH3 in			
	Ethernet > Ports > Port Settings.			
IP Address	Set the IP address of the LAN port.	192.168.0.1		
Netmask	Set the Netmask of the LAN port.	255.255.255.0		
MTU	Enter the Maximum Transmission Unit.	1500		
VLAN ID	Enter the VLAN ID corresponding to the lan interface to divide the eth interface	0		
	in the same lan into the same vlan.			

Dec. 29, 2020

RT_UG_R5020_v.1.0.0

4.2.2 LAN

This section allows you to set the related parameters for LAN port. There are four LAN ports on R5020 Router, including ETH0, ETH1, ETH2 and ETH3. ETH0 is wan by default and is not selectable. The ETH1, ETH2 and ETH3 can freely choose from lan0, lan1 and lan2, but at least one LAN port must be assigned as lan0. The default settings of ETH0, ETH1, ETH2 and ETH3 are lan0 and their default IP are 192.168.0.1/255.255.255.0.

LAN

LAN	4	Multiple IP	Si	tatus
∧ Netwo	ork Setting	s		
Index	Interface	IP Address	Netmask	VLAN ID
1	lan0	192.168.0.1	255.255.255.0	0





The window is displayed as below when choosing "Server" as the mode.

∧ DHCP Settings	
Enable	ON OFF
Mode	Server
IP Pool Start	192.168.0.2
IP Pool End	192.168.0.100
Subnet Mask	255.255.255.0
A DHCP Advanced Settings	
Gateway	
Primary DNS	
Secondary DNS	
WINS Server	
Lease Time	120
Static lease	
Expert Options	
Debug Enable	ON OFF

The window is displayed as below when choosing "Relay" as the mode.

∧ DHCP Settings	
Enable	ON OFF
Mode	Relay
DHCP Server For Relay	
A DHCP Advanced Settings	
Debug Enable	ON OFF

LAN				
Item	Description	Default		
	DHCP Settings			
Enable	Click the toggle button to enable/disable the DHCP function.	ON		
Mode	Select from "Server" or "Relay".	Server		
	Server: Lease IP address to DHCP clients which have been			
	connected to LAN port			
	Relay: Router can be DHCP Relay, which will provide a relay			
	tunnel to solve problem that DHCP Client and DHCP Server is not			
	in a same subnet			
IP Pool Start	Define the beginning of the pool of IP addresses which will be leased	192.168.0.2		
	to DHCP clients.			



	LAN				
Item	Description	Default			
IP Pool End	Define the end of the pool of IP addresses which will be leased to				
	DHCP clients.				
Subnet Mask	Define the subnet mask of IP address obtained by DHCP clients from	255.255.255.0			
	DHCP server.				
DHCP Server for Relay	Enter the IP address of DHCP relay server.	Null			
	DHCP Advanced Settings	•			
Router	Define the router assigned by the DHCP server to the clients, which	Null			
	must be on the same network segment with DHCP address pool.				
Primary DNS	Define the primary DNS server assigned by the DHCP server to the	Null			
	clients.				
Secondary DNS	Define the secondary DNS server assigned by the DHCP server to the	Null			
	clients.				
WINS Server	Define the Windows Internet Naming Service obtained by DHCP	Null			
	clients from DHCP sever.				
Lease Time	Set the lease time which the client can use the IP address obtained	120			
	from DHCP server, measured in seconds.				
Static lease	Bind a lease to correspond an IP address via a MAC address.	Null			
	format: mac,ip;mac,ip;, e.g. FF:ED:CB:A0:98:01,192.168.0.200				
Expert Options	Enter some other options of DHCP server in this field.	Null			
	format: config-desc;config-desc, e.g. log-dhcp;quiet-dhcp				
Debug Enable	Click the toggle button to enable/disable this option. Enable for DHCP	OFF			
	information output.				

Multiple IP

LAN Multiple IP		Status		
^ Multip	le IP Setti	ngs		
Index	Interface	IP Address	Netmask	+

You may click 🕂 to add a multiple IP to the LAN port, or click 🗙 to delete the multiple IP of the LAN port. Now, click 📝 to edit the multiple IP of the LAN port.

Multiple IP	
∧ IP Settings	
Index	1
Interface	lan0 v
IP Address	172.16.24.24
Netmask	255.255.0.0
	Submit Close



IP Settings			
Item Description		Default	
Index	Indicate the ordinal of the list.		
Interface	Show the editing port, read only.		
IP Address	Set the multiple IP address of the LAN port.	Null	
Netmask	Set the multiple Netmask of the LAN port.	Null	

Status

This section allows you to view the status of LAN connection.

LAN	М	ultiple IP	Status		
∧ Interfa	ce Status				
Index	Interface	IP Address M	IAC Address		
1	lan0 19	92.168.0.1/255.2 34:	FA:40:0B:68:A	с	
^ Connec	ted Devices				
Index	IP Address	MAC Address	Interface	Inactive Time	
1	192.168.0.5	D4:3A:65:05:FC:44	A lan0	Os	
∧ DHCP L	ease Table.				
Index	IP Address	MAC Address	Interface	Expired Time	
1	192.168.0.5	d4:3a:65:05:fc:4a	lan0	0 days, 01:51:32	

Click the row of status, the details status information will be display under the row. Please refer to the screenshot below.

∧ Interfa	∧ Interface Status							
Index	Interface	IP Address MA	C Address					
1	lan0	192.168.0.1/255.2 34:FA	:40:0B:68:AC					
		Index	1					
		Interface	lan0					
		IP Address	192.168.0.1/255.255.255.0					
		MAC Address	34:FA:40:0B:68:AC					
		RX Packets	14470					
		TX Packets	12759					
		RX Bytes	2849614					
		TX Bytes	10657230					

4.2.3 Ethernet

This section allows you to set the related parameters for Ethernet. There are four Ethernet ports on R5020 Router, including ETH0, ETH1, ETH2 and ETH3. The ETH0 on the router can be configured as a WAN port, while ETH1, ETH2 and ETH3 can only be configured as a LAN port. By default, ETH1, ETH2 and ETH3 are lan0, and their IP are



192.168.0.1/255.255.255.0.

Ports		Status	
∧ Port Settings			0
Index	Port	Port Assignment	
1	eth0	wan	
2	eth1	lan0	
3	eth2	lan0	
4	eth3	lan0	

Click Sutton of eth1 to configure its parameters. Modify the network port parameters in the pop-up port window.

Ports	
∧ Port Settings	
Index	2
Port	eth1 v
Port Assignment	lan0 v 🦻

Ports		0	O Annie – Debe
∧ Port Settings			
Index	2		
Port	eth1 v		
Port Assignment	lan0 v	7	
	lan1	Submit	Close
3 eth2 lan0	lan2 wan		

Port Settings				
Item	Description	Default		
Index	Indicate the ordinal of the list.			
Port	Show the editing port, read only.			
Port Assignment	Select the type of network port, WAN port or LAN port. When set it as LAN port in "Interface > LAN > LAN > Network Settings > General Setting", can select lan0 or lan1 or lan2 from the drop-down box.	Lan0		

Advanced Settings

SFE Fast ON OFF

Port Settings				
Item	Description	Default		
SFE Fast	Enabling SFE Fast improves the throughput of the Ethernet or cellular module, but	ON		
	affects the QoS function. If you need to use QoS APP, you need to turn off the SFE			
	Fast function.			



This column allows you to view the status of Ethernet port.

Ports		Status
∧ Port Sta	itus	
Index	Port	Link
1	eth0	Down
2	eth1	Down
3	eth2	Down
4	eth3	Up

Click the row of status, the details status information will be display under the row. Please refer to the screenshot below.

Ports		Status		
∧ Port Status				
Index	Port	Link		
1	eth0	Down		
2	eth1	Down		
3	eth2	Down		
4	eth3	Up		
			Index	4
			Port	eth3
			Link	Up

4.2.4 Cellular

This section allows you to set the related parameters of Cellular. The R5020 Router has two SIM card slots. If insert single SIM card at the first time, SIM1 slot and SIM2 slots are available.

Cellular		Status	AT Debug			
∧ Advanced Cellular Settings						
Index	SIM Card	Phone Number	Network Type	Band Select Type		
1	SIM1		Auto	All		
2	SIM2		Auto	All		

Click of SIM 1 to edit the parameters.

Cellular	
∧ General Settings	
Index	1
SIM Card	SIM1 V
Phone Number	
PIN Code	0
Extra AT Cmd	0
Telnet Port	0 🤇



The window is displayed as below when choosing "Auto" as the network type.

∧ Cellular Network Settings							
Network Type		Auto 🗸 🧿					
B	and Select Type	All v					
Advanced Settings							
	Debug Enable	ON OFF					
Verbos	e Debug Enable	ON OFF					

The window is displayed as below when choosing "Specify" as the band select type.

∧ Cellular Network Settings						
	Network Type	Auto	▼ 7			
	Band Select Type	Specify	⊻ ?			



Cellular						
Item	Default					
	General Settings					
Index	Indicate the ordinal of the list.					
SIM Card	Set the currently editing SIM card.	SIM1				
Phone Number	Enter the phone number of the SIM card.	Null				
PIN Code	Enter a 4-8 characters PIN code used for unlocking the SIM.	Null				





Cellular					
Item	Description	Default			
Extra AT Cmd	Enter the AT commands used for cellular initialization.	Null			
Telnet Port	Specify the Port listening of telnet service, used for AT over Telnet.	0			
	Cellular Network Settings				
Network Type	Select from "Auto", "3G Only", and "4G Only".	Auto			
	Auto: Connect to the best signal network automatically				
	3G Only: Only the 3G network is connected				
	4G Only: Only the 4G network is connected				
Band Select Type	Select from "All" or "Specify". You may choose certain bands if choosing	All			
	"Specify".				
	Advanced Settings				
Debug Enable	Click the toggle button to enable/disable this option. Enable for debugging	ON			
	information output.				
Verbose Debug	Click the toggle button to enable/disable this option. Enable for verbose	OFF			
Enable	debugging information output.				
Network	The timeout required for the module to register to the network. 0 indicates that	0			
Registration	the default configuration is used.				
Timeout					

This section allows you to view the status of the cellular connection.

Cellular		Stati	ıs	AT Del					
^ Status									
Index	Mode	m Status	Moden	n Model	IMS	51	F	Registration	
1	R	leady	RM50	0QGL	460110403	3884191		Registered	



Click the row of status, the details status information will be displayed under the row.

∧ Status				
Index	Modem Status	Modem Model	IMSI	Registration
1	Ready	RM500QGL	460046578605525	Registered
		Index	1	
		Modem Status	Ready	
		Modem Model	RM500QGL	
		Current SIM	SIM1	
		Phone Number		
		IMSI	460046578605525	
		ICCID	89860445101941192968	
		Registration	Registered	
		Network Provider	CHINA MOBILE	
		Network Type	5G	
		Band	41	
		Signal Strength	31 (-51dBm)	
		RSRP	-67 dBm	
		RSRQ	-11 dB	
		SINR	31 dB	
		Bit Error Rate	99	
		PLMN ID	46000	
		Local Area Code		
		Cell ID		
		Physical Cell ID	532	
		IMEI	863305040165010	
		Firmware Version	RM500QGLABR11A02M4G	

	Status					
Item	Description					
Index	Indicate the ordinal of the list.					
Modem Status	Show the status of the radio module.					
Modem Model	Show the model of the radio module.					
Current SIM	Show the SIM card that your router is using: SIM1 or SIM2					
Phone Number	Show the phone number of the current SIM.					
	Note: This option will be displayed if enter manually in Cellular > Advanced Cellular					
	Settings > SIM1/SIM2 > Phone Number.					
IMSI	Show the IMSI number of the current SIM.					
ICCID	Show the ICCID number of the current SIM.					
Registration	Show the current network status.					
Network Provider	Show the name of Network Provider.					
Network Type	Show the current network service type, e.g. GPRS.					
Band	Show the band of the current network.					
Signal Strength	Show the signal strength detected by the mobile.					
RSRP	Show the Reference Signal Receiving Power detected by the mobile.					
RSRQ	Show the Reference Signal Received Quality detected by the mobile.					
SINR	Show the Signal to Interference plus Noise Ratio detected by the mobile.					
Bit Error Rate	Show the current bit error rate.					
PLMN ID	Show the current PLMN ID.					
Local Area Code	Show the current local area code used for identifying different area.					
Cell ID	Show the current cell ID used for locating the router.					



Status				
Item	Description			
PCI	Show the current Physical Cell ID.			
IMEI	Show the IMEI (International Mobile Equipment Identity) number of the radio			
	module.			
Firmware Version	Show the current firmware version of the radio module.			

This page allows you to check the AT Debug.

Cellular	Status	AT Debug	
∧ At Debug			
Command			
Result			
			Send

AT Debug						
Item	Description	Default				
Command	Enter the AT command that you want to send to cellular module in this text box.	Null				
Result	Show the AT command responded by cellular module in this text box.	Null				
Send	Click the button to send AT command.					

10 robustel

4.2.5 WiFi

This section allows you to configure the parameters of two WiFi modes. Router supports either WiFi AP mode or Client mode, and defaults as AP.

WiFi AP

Configure Router as WiFi AP

Click Interface > WiFi > WiFi, select "AP" as the mode and click "Submit".

WiFi	Access Point 2G	Access Point	: 5G	Status	
∧ General Setti	ngs				
		Mode A	P	v 😨	
		Region S	E	0	

Note: Please remember to click **Save & Apply** after finish the configuration, so that the configuration can be took effect.

Click the **Access Point 2G** column to configure the parameters of WiFi AP. By default, the security mode is set as "Disabled".

WiFi	Access Point 2G	Access Po	oint 5G	Status		
∧ General Settin	gs					
		Enable	ON OF	F		
	Wire	eless Mode	11bgn M	ixed v		
		Bandwidth	20MHz	v	?	
		Channel	Auto	v	?	
		SSID	router2g			
	Broad	icast SSID	ON OF			
	Sec	urity Mode	Disabled	v	?	



The window is displayed as below when setting "WPA-Personal" as the security mode.

WiFi	Access Point 2G Acc	ess Point 5G	Status				
∧ General Settings							
	En	able ON OFF					
	Wireless M	lode 11bgn Mixed	v				
	Bandw	idth 20MHz	v 😨				
	Cha	nnel Auto	v 🦻				
	5	sID router2g					
	Broadcast S	SID ON OFF					
	Security M	lode WPA-Personal	v				
	WPA Ver	sion Auto	V				
	Encryp	tion AES	v				
	PSK Passv	vord					
	Group Key Update Inte	rval 3600					

The window is displayed as below when setting "WEP" as the security mode.

∧ General Settings	
Enable	ON OFF
Wireless Mode	11bgn Mixed v
Bandwidth	20MHz 🥑 🖓
Channel	Auto 🗸 🧭
SSID	router2g
Broadcast SSID	ON OFF
Security Mode	WEP 🥑 🍞
WEP Key	0

General Settings @ Access Point 2G				
Item	Description	Default		
Enable	Click the toggle button to enable/disable the WiFi	OFF		
	access point option.			
Wireless Mode	Select from "11bgn Mixed", "11b only", "11g only" and	11bgn Mixed		
	"11n only".			
	11bgn Mixed: mix three protocols for backward			
	compatibility			
	• 11b only: IEEE 802.11b, 11 Mbps~2.4GHz			
	• 11g only: IEEE 802.11g, 54 Mbps~2.4GHz			
	• 11n only: IEEE 802.11n, 450 Mbps			



	General Settings @ Access Point 2G	
Item	Description	Default
Bandwidth	Select from "20 MHz" or "40MHz".	20MHz
	Note: 40 MHz channel width provides twice the data	
	rate available over a single 20 MHz channel;	
	The channel that different bandwidth can choose is as	
	follows.	
	Auto: Router will scan all frequency channels until	
	the best one is found	
	The frequency of 1~13 channels of 20MHz	
	bandwidth available channel:	
	1–2412 MHz	
	2–2417 MHz	
	3–2422 MHz	
	4–2427 MHz	
	5–2432 MHz	
	6–2437 MHz	
	7–2442 MHz	
	8–2447 MHz	
	9–2452 MHz	
	10–2457 MHz	
Channel	11–2462 MHz	Auto
Channel	12–2467 MHz	Auto
	13–2472 MHz	
	• The frequency of 1~13 channels of 40MHz	
	bandwidth available channel:	
	1–2412 MHz	
	2–2417 MHz	
	3–2422 MHz	
	4–2427 MHz	
	5–2432 MHz	
	6–2437 MHz	
	7–2442 MHz	
	8–2447 MHz	
	9–2452 MHz	
	10–2457 MHz	
	11–2462 MHz	
	12–2467 MHz	
	13–2472 MHz	
SSID	Enter the Service Set Identifier, the name of your	router2g
	wireless network. The SSID of a client and the SSID of	
	the AP must be identical for the client and AP to be able	
	to communicate with each other. Enter 1 to 32	
	characters.	



General Settings @ Access Point 2G				
Item	Description	Default		
Broadcast SSID	Click the toggle button to enable/disable the SSID being broadcast. When enabled, the client can scan your SSID. When disabled, the client cannot scan your SSID. If you want to connect to the router AP, you need to manually enter the SSID of router AP at WiFi client side.	ON		
Security Mode	 Select from "Disabled", "WPA-Personal" or "WEP". Disabled: User can access the WiFi without password Note: It is strongly recommended for security purposes that you do not choose this kind of mode. WPA-personal: WiFi access protection, only one password is provided for identity authentication WEP: Wired Equivalent Privacy provides encryption for wireless device's data transmission 	Disabled		
WPA Version	 Select from "Auto", "WPA" or "WPA2". Auto: Router will choose automatically the most suitable WPA version WPA2 is a stronger security feature than WPA 	Auto		
Encryption	 Select from "TKIP" or "AES". TKIP: Temporal Key Integrity Protocol (TKIP) encryption uses a wireless connection. TKIP encryption can be used for WPA-PSK and WPA 802.1x authentication AES: AES encryption uses a wireless connection. AES can be used for CCMP WPA-PSK and WPA 802.1x authentication. AES is a stronger encryption algorithm than TKIP Note: The security mode will affect wireless communication rate. Different wireless modes support different encryption modes. For example, 802.11n supports neither WEP security mode nor TKIP algorithm. If they are used, the wireless communication rate will reduce to 54Mbps (802.11g mode). It is recommended to select AES in 802.11n mode. 	AES		
PSK Password	Enter the Pre share key password. Enter 8 to 63 characters.	Null		
Group Key Update Interval	Enter the time period of group key renewal.	3600		
WEP Key	Enter the WEP key. The key length should be 10 or 26 hexadecimal digits depending on which WEP key is used, 64 digits or 128 digits.	Null		



 Advanced Settings 	
Max Associated Stations	0 7
Beacon Interval	100 🥱
DTIM Period	2
RTS Threshold	2347 🥱
Fragmentation Threshold	2346 🥱
Transmit Rate	Auto
11N Transmit Rate	Auto
Transmit Power	Max
Enable WMM	ON OFF
Enable Short GI	ON OFF ?
Enable AP Isolation	ON OFF ?
Debug Level	none v

Advanced Settings @ Access Point 2G				
Item	Description			
Max Associated Stations	Set the max number of clients allowed to access the router's AP.	0		
	(Value 0 means without limitation)			
Beacon Interval	Set the interval of time in which the router AP broadcasts a beacon	100		
	which is used for wireless network authentication.			
DTIM Period	Set the delivery traffic indication message period and the router AP	2		
	will multicast the data according to this period.			
RTS Threshold	Set the "request to send" threshold. When the threshold set as	2347		
	2347, the router AP will not send detection signal before sending			
	data. And when the threshold set as 0, the router AP will send			
	detection signal before sending data.			
Fragmentation Threshold	Set the fragmentation threshold of a WiFi AP. It is recommended that	2346		
	you use the default value 2346.			
Transmit Rate	Set the transmit rate. You can choose Auto or specify a Transmit	Auto		
	Rate, including 1Mbps, 2Mbps, 5.5Mbps, 6Mbps, 11Mbps, 12Mbps,			
	18Mbps, 24Mbps, 36Mbps, 48Mbps and 54Mbps.			
11N Transmit Rate	Specify the transmit rate under the IEEE 802.11n mode or let is	Auto		
	default to "Auto". Select from MCS0, MCS1, MCS2, MCS3, MCS4,			
	MCS5, MCS6, MCS7, MCS8, MCS9, MCS10, MCS11, MCS12, MCS13,			
	MCS14 and MCS15.			
Transmit Power	Select from "Max", "High", "Medium" or "Low".	Max		
Enable WMM	Click the toggle button to enable/disable the WMM option.	ON		
Enable Short GI	Click the toggle button to enable/disable the Short Guard Interval	ON		
	option. Short GI is a blank time between two symbols, providing a			
	long buffer time for signal delay. Using the Short GI would increase			
	11% in data rates, but also result in higher packet error rates.			



Advanced Settings @ Access Point 2G			
Item	Default		
Enable AP Isolation	Click the toggle button to enable/disable the AP isolation option.	OFF	
	When enabled, the router will isolate all connected wireless devices.		
	The wireless device cannot access the router directly via WLAN.		
Debug Level	Select from "verbose", "debug", "info", "notice", "warning" or	none	
	"none".		

ACL Set	tings		
Enable ACL			ON OFF
		ACL Mode	Accept v
Access	Control List		
Index	Description	MAC Address	+

Click + to add a MAC address to the Access Control List. The maximum count for MAC address is 64.

Access Point 2G	
Access Control List	
Index	1
Description	
MAC Address	

ACL Settings @ Access Point 2G				
Item	Description Default			
Enable ACL	Click the toggle button to enable/disable this option.	OFF		
ACL Mode	Select from "Accept" or "Deny".	Accept		
	• Accept: Only the packets fitting the entities of the "Access Control			
	List" can be allowed			
	Deny: All the packets fitting the entities of the "Access Control			
	List" will be denied			
	Note: Router can only allow or deny devices which are included in			
	"Access Control List" at one time.			
Access Control List @ Access Point 2G				
Index	Indicate the ordinal of the list.			
Description	Enter a description for this access control list. Null			
MAC Address	Add a MAC address here. Null			

Click the **Access Point 5G** column to configure the parameters of WiFi AP. By default, the security mode is set as "Disabled".



WiFi	Access Point 2G	Access Po	oint 5G	Status			
∧ General Settin	∧ General Settings						
		Enable	ON OFF				
	Wirel	ess Mode	11an	v			
	В	andwidth	20MHz	v			
		Channel	36	v			
		SSID	router5g				
	Broade	cast SSID	ON OFF				
	Secu	rity Mode	Disabled	v ?			

The window is displayed as below when setting "WPA-Personal" as the security mode.

WiFi	Access Point 2G	Access Po	oint 5G	Status		
∧ General Settings						
	Enable			F		
	Wire	less Mode	11an	v		
	В	andwidth	20MHz	v 🕝		
		Channel	36	v		
		SSID	router5g			
	Broadcast SSID			T.		
	Secu	rity Mode	WPA-Pers	sonal v 🤊		
	WP	A Version	Auto	v		
	E	ncryption	AES	v		
PSK Password				7		
Group Key Update Interval			3600			

The window is displayed as below when setting "WEP" as the security mode.

WiFi	Access Point 2G	Access Po	oint 5G	Status	
∧ General Settin	gs				
		Enable	ON OFF		
	Wire	less Mode	11an	v	
	В	andwidth	20MHz	v ?	
	Channel			v	
		SSID	router5g		
	Broad	cast SSID	ON OFF)	
	Secu	rity Mode	WEP	v ?	
		WEP Key		•	



	General Settings @ Access Point 5G	
Item	Description	Default
Enable	Click the toggle button to enable/disable the WiFi	OFF
	access point option.	
Wireless Mode	Select from "11an", or "11/a/an/ac".	11an
	• 11an : Compatible IEEE 802.11a, 54 Mbps and IEEE	
	802.11n, 300Mbps	
	• 11n/a/an/ac: Compatible IEEE 802.11a, 54 Mbps,	
	IEEE802.11n 300 Mbps and 802.11ac, 867 Mbps	
Bandwidth	Select from "20MHz", "40MHz" or "80MHz".	20MHz
	Note: 40 MHz channel width provides twice the data	
	rate available over a single 20 MHz channel; the data	
	transfer rate of 80MHz bandwidth is 4 times greater	
	than that of a single 20Mhz bandwidth.	
	The optional channels for bandwidths are as below.	
	 The frequency of 36~165 channels of 20MHz 	
	bandwidth available channels:	
	36–5180 MHz	
	40–5200 MHz	
	44–5220 MHz	
	48–5240 MHz	
	149–5745 MHz	
	153–5765 MHz	
	157–5785 MHz	
	161–5805 MHz	
	165–5825 MHz	
	 The frequency of 36~165 channels of 40MHz 	
	bandwidth available channels:	
	36–5180 MHz	
Channel	40–5200 MHz	36
	44–5220 MHz	
	48–5240 MHz	
	149–5745 MHz	
	153–5765 MHz	
	157–5785 MHz	
	161–5805 MHz	
	165–5825 MHz	
	 The frequency of 36~165 channels of 80MHz 	
	bandwidth available channels:	
	36–5180 MHz	
	40–5200 MHz	
	44–5220 MHz	
	48–5240 MHz	
	149–5745 MHz	
	153–5765 MHz	



General Settings @ Access Point 5G				
Item	Description	Default		
	157–5785 MHz			
	161–5805 MHz			
	165–5825 MHz			
	Note: All available channels of 5GHz WiFi in different			
	bandwidths are listed above. Web parameters should			
	be configured due to the different available channels in			
	different countries and areas.			
SSID	Enter the Service Set Identifier, the name of your	router5g		
	wireless network. The SSID of a client and the SSID of			
	the AP must be identical for the client and AP to be able			
	to communicate with each other. Enter 1 to 32			
	characters.			
Broadcast SSID	Click the toggle button to enable/disable the SSID being	ON		
	broadcast. When enabled, the client can scan your			
	SSID. When disabled, the client cannot scan your SSID.			
	If you want to connect to the router AP, you need to			
	manually enter the SSID of router AP at WiFi client side.			
Security Mode	Select from "Disabled", "WPA-Personal", or "WEP".	Disabled		
	Disabled: User can access the WiFi without			
	password			
	Note: It is strongly recommended for security			
	purposes that you do not choose this kind of			
	mode.			
	WPA-personal: WiFi access protection, only one			
	password is provided for identity authentication			
	WEP: Wired Equivalent Privacy provides encryption			
	for wireless device's data transmission			
WPA Version	Select from "Auto", "WPA" or "WPA2".	Auto		
	Auto: Router will choose automatically the most			
	suitable WPA version			
	WPA2 is a stronger security feature than WPA			



General Settings @ Access Point 5G				
Item	Description	Default		
Encryption	Select from "TKIP" or "AES".	AES		
	TKIP: Temporal Key Integrity Protocol (TKIP)			
	encryption uses a wireless connection. TKIP			
	encryption can be used for WPA-PSK and WPA			
	802.1x authentication			
	• AES: AES encryption uses a wireless connection.			
	AES can be used for CCMP WPA-PSK and WPA			
	802.1x authentication. AES is a stronger encryption			
	algorithm than TKIP			
	Note: The security mode will affect wireless			
	communication rate. Different wireless modes support			
	different encryption modes. For example, 802.11n			
	supports neither WEP security mode nor TKIP			
	algorithm. If they are used, the wireless communication			
	rate will reduce to 54Mbps (802.11g mode). It is			
	recommended to select AES in 802.11n mode.			
PSK Password	Enter the Pre share key password. Enter 8 to 63	Null		
	characters.			
Group Key Update Interval	Enter the time period of group key renewal.	3600		
WEP Key	Enter the WEP key. The key length should be 10 or 26	Null		
	hexadecimal digits depending on which WEP key is			
	used, 64 digits or 128 digits.			

Advanced Settings	
Max Associated Stations	64 7
Beacon Interval	100 🥱
DTIM Period	2
RTS Threshold	2347 🥱
Fragmentation Threshold	2346 🥱
Transmit Power	Max
Enable WMM	ON OFF
Enable Short GI	ON OFF ?
Enable AP Isolation	ON OFF ?
Debug Level	none v

Advanced Settings @ Access Point 5G				
Item	Description	Default		
Max Associated Stations	Set the max number of clients allowed to access the router's AP.	0		
(Value 0 means without limitation)				



Advanced Settings @ Access Point 5G			
Item	Description	Default	
Beacon Interval	acon Interval Set the interval of time in which the router AP broadcasts a beacon		
	which is used for wireless network authentication.		
DTIM Period	Set the delivery traffic indication message period and the router AP	2	
	will multicast the data according to this period.		
RTS Threshold	Set the "request to send" threshold. When the threshold set as	2347	
	2347, the router AP will not send detection signal before sending		
	data. And when the threshold set as 0, the router AP will send		
	detection signal before sending data.		
Fragmentation Threshold	tation Threshold Set the fragmentation threshold of a WiFi AP. It is recommended that		
	you use the default value 2346.		
Transmit Power	Select from "Max", "High", "Medium" or "Low".	Max	
Enable WMM	Click the toggle button to enable/disable the WMM option.	ON	
Enable Short GI	Click the toggle button to enable/disable the Short Guard Interval	ON	
	option. Short GI is a blank time between two symbols, providing a		
	long buffer time for signal delay. Using the Short GI would increase		
	11% in data rates, but also result in higher packet error rates.		
Enable AP Isolation	Click the toggle button to enable/disable the AP isolation option.	OFF	
	When enabled, the router will isolate all connected wireless devices.		
	The wireless device cannot access the router directly via WLAN.		
Debug Level	Select from "verbose", "debug", "info", "notice", "warning" or	none	
	"none".		

∧ ACL Set	tings		
		Enable ACL	ON OFF
		ACL Mode	Accept 🥑
^ Access	Control List		
Index	Description	MAC Address	+

Click + to add a MAC address to the Access Control List. The maximum count for MAC address is 64.

Access Control List	
Index	1
Description	
MAC Address	

ACL Settings @ Access Point 5G			
Item	Description	Default	
Enable ACL	Click the toggle button to enable/disable this option.	OFF	
ACL Mode	Select from "Accept" or "Deny".		
Accept: Only the packets fitting the entities of the "Access Control			



ACL Settings @ Access Point 5G				
Item Description Defa				
	List" can be allowed			
	Deny: All the packets fitting the entities of the "Access Control			
	List" will be denied			
	Note: Router can only allow or deny devices which are included in			
	"Access Control List" at one time.			
	Access Control List @ Access Point 5G			
Index	Indicate the ordinal of the list.			
Description	Enter a description for this access control list.	Null		
MAC Address	Add a MAC address here.	Null		

This section allows you to view the status of AP.

WiFi	Access	5 Point 2G	oint 2G Access Point 5G		Status		
AP Stat	us 2G						
			Status	FAILED			
			Channel				
		Char	nnel Width				
		МА	C Address				
^ Associa	ted Stations 2	G					
Index	MAC Address	IP Addr	ess	Name	Connected Time	e Signal	
✓ AP Stat	✓ AP Status 5G						
^ Associa	∧ Associated Stations 5G						
Index	MAC Address	IP Addr	ess	Name	Connected Time	e Signal	

Note: WiFi is off by default. Follow the steps below to enable it and configure the router as WiFi client.

WiFi Client

Configure Router as WiFi Client

Click Interface > WiFi > WiFi, select "Client" as the mode and regarding the AP type to choose the related Client Band then click "Submit".

WiFi		
∧ General Setti	ngs	
	Mode	Client v
	Region	SE

And then a "WLAN" column will appear under the Interface list.

	WiFi
Status	∧ General Settings
Interface	Mode Client v
Link Manager	Region SE
LAN	
Ethernet	
Cellular	
WiFi 🔦	
WLAN	

Click **Interface > Link Manager > Link Settings**, and click the edit button of WLAN, then configure its related parameters.

∧ WLAN Settings	
SSID	router
Connect to Hidden SSID	ON OFF
Password	

Click Interface > WLAN to configure the parameters of WiFi Client after setting the mode as Client. Please remember to click Save & Apply > Reboot after finish the configuration, so that the configuration can be took effect.

Status		
~ WLAN Status		
	Status	Connected
	Uptime	0 days, 00:00:17
	IP Address	192.168.1.128/255.255.255.0
	Gateway	192.168.1.253
	DNS	172.16.0.1 202.96.209.6
	MAC Address	00:23:a7:a4:13:e4

4.2.6 USB

This section allows you to set the USB parameters. The USB interface of the router can be used for firmware upgrade and configuration upgrade.

USB	Key	
∧ General Settin	gs	
	En	able USB ON OFF
	Enable Automatic	Upgrade ON OFF




General Settings @ USB			
Item	Description	Default	
Enable USB	Click the toggle button to enable/disable the USB option.	ON	
Enable Automatic	Click the toggle button to enable/disable this option. Enable to automatically	OFF	
Upgrade	update the firmware of the router when inserting a USB storage device with a		
	router firmware.		
	Кеу		
Item	Description	Default	
USB Automatic Update	Click Generate to generate a key, and click Download to download the key.		
Кеу			

Note: In the process of USB auto upgrade, when using the USB auto-upgrade function, when the running light appears, it means the upgrade is in progress. When the running light stops and the USER light is on, it means the upgrade is complete. After upgrading, the device will not restart automatically. If there is no running light effect, it means that there is an abnormality and it does not enter into the automatic upgrade process

4.2.7 DI/DO

This section allows you to set the DI/DO parameters. Digital Input and Digital Output are the specific interfaces for R5020. The DI interface can be used for triggering alarm, while the DO can be used for controlling the slave device so as to realize real-time monitoring.

DI

DI		DO		Status			
∧ DI Set	tings						
Index	Enable	Mode	Inversion				
1	false	ON-OFF	false				



Click the right-most Z button of index 1 as below. The default mode is "ON-OFF".

DI	
∧ General Settings	
Index	1
Enable	ON OFF
Mode	ON-OFF v
Inversion	ON OFF
Alarm On Content	Alarm On
Alarm Off Content	Alarm Off

The window is displayed as below when choosing "Counter" as the mode.

DI	
∧ General Settings	
Index	1
Enable	ON OFF
Mode	Counter
Inversion	ON OFF
Threshold Value	0
Alarm On Content	Alarm On
Alarm Off Content	Alarm Off

General Settings @ DI			
Item	Description	Default	
Index	Indicate the ordinal of the list.		
Enable	Click the toggle button to enable/disable this DI.	OFF	
Mode	Select from "ON-OFF" or "Counter".	ON-OFF	
	• ON-OFF: DI interface support ON and OFF mode (high or low level		
	electrical) trigger DI alarm. The mode default to ON, and OFF mode is		
	available only when enabling the inversion feature		
	ON—Under this mode, DI alarm status will be triggered to ON when DI		
	interface open from GND or input a high level electrical (logic 1), on the		
	contrary DI alarm status will be trigged to OFF when DI interface connect		
	to GND or input a low level electrical (logic 0)		
	OFF—Under this mode, DI alarm status will be triggered to ON when DI		
	interface connect to GND or input a low level electrical (logic 0), on the		
	contrary DI alarm status will be trigged to OFF when DI interface open		
	from GND or input a high level electrical (logic 1)		
	Counter: Event counter mode		
Inversion	Click the toggle button to enable/disable this option. Enable to set DI mode as	OFF	
	OFF mode.		
Threshold Value	Set the threshold vale. It will trigger alarm when event counter reaches this	0	



General Settings @ DI			
Item	Description	Default	
	figure. After triggering alarm, DI will keep counting but not trigger alarm		
	again. Enter 0 to 65535 digits. (0=will not trigger alarm)		
	Note: This option is only available when DI under the "Counter" mode.		
Alarm On Content	Show the content when alarm on.	Alarm On	
Alarm Off Content	Show the content when alarm off.	Alarm Off	

Note: It defaults as high alarm, while turns to low alarm after enabling the "Inversion" button.

DO

DI		DO	Status			
∧ DO Set	tings					
Index	Enable	Alarm On Action	Alarm Off Action	Initial State	Alarm Source	
1	false	High	Low	Last	DI1 Alarm	

Click 📝 to enter the DO configuration window.

DO	
∧ General Settings	
Index	1
Enable	ON OFF
Alarm On Action	High
Alarm Off Action	Low
Initial State	Last
Delay	0 7
Hold Time	0 7
Alarm Source	DI1 Alarm v



The window is displayed as below when choosing "Pulse" as the alarm on action.

∧ General Settings	
Index	1
Enable	ON OFF
Alarm On Action	Pulse
Alarm Off Action	Low
Initial State	Last
Delay	0 ()
Hold Time	0 🤇
Low-level Width	10
High-level Width	10 🤇
Alarm Source	DI1 Alarm v

The window is displayed as below when choosing "Pulse" as the alarm off action.

∧ General Settings	
Index	1
Enable	ON OFF
Alarm On Action	High
Alarm Off Action	Pulse
Initial State	Last
Delay	0 ()
Hold Time	0 ()
Low-level Width	10 🦻
High-level Width	10 🦻
Alarm Source	DI1 Alarm v

General Settings @ DO			
Item	Description	Default	
Index	Indicate the ordinal of the list.		
Enable	Click the toggle button to enable/disable this DO.	OFF	
Alarm On Action	Digital Output initiates when there is an alarm. Selected from "High", "Low" or "Pulse".	High	
	 High: a high electrical level output Low: a low electrical level output Pulse: Generates a square wave as specified in the pulse mode parameters when triggered 		



	General Settings @ DO	
Item	Description	Default
Alarm Off	Digital Output initiates when alarm removed. Selected from "High", "Low" or "Pulse".	Low
Action	High: a high electrical level output	
	Low: a low electrical level output	
	• Pulse: Generates a square wave as specified in the pulse mode parameters when	
	triggered	
Initial State	Specify the Digital Output status when powered on. Selected from "Last", "High" or	Last
	"Low".	
	Last: DO's status will consist with the status of last power off	
	High: DO interface is in high electrical level	
	Low: DO interface is in low electrical level	
Delay	Set the delay time for DO alarm start-up. The first pulse will be generated after a	0
	"Delay". Enter from 0 to 300000ms. (0=generate pulse without delay)	
Hold Time	Set the hold time of DO status (Alarm On Action/Alarm Off Action). When the action	0
	time reach this specified time, DO will stop the action. Enter from 0 to 3000 seconds.	
	(0=keep on until the next action)	
Low-level Width	Set the low-level width. It is available when enabling Pulse as "Alarm On Action/Alarm	1000
	Off Action". In Pulse Output mode, the selected digital output channel will generate a	
	square wave as specified in the pulse mode parameters. The low level widths are	
	specified here. Enter from 1 to 3000 ms.	
High-level	Set the high-level width. It is available when enabling Pulse as "Alarm On	1000
Width	Action/Alarm Off Action". In Pulse Output mode, the selected digital output channel	
	will generate a square wave as specified in the pulse mode parameters. The high level	
	widths are specified here. Enter from 1 to 3000 ms.	
Alarm Source	Digital Output initiates according to different alarm source. Selected only "DI1 Alarm".	DI1
	DI1 Alarm: Digital Output triggers the related action when there is alarm from Digital	
	Input.	

Status

This window allows you to view the status of DO and DI interface. It also can clear the counter alarm of DI in here. Click Clear button to clear DI1 or DI2 monthly usage statistics info for counter alarm.



DI		DO		Status
^ DI Sta	tus			
Index	Level	Status	Count	
1	Low	Alarm off		
^ Action	Of Clear			
		Count	ter Alar	m Of DI 1 Clear
^ DO Sta	atus			
Index	Level	Low-level \	Width	High-level Width
1	Low			
A DO Coi	ntrol			
			Lev	el Of DO1 Togg

4.2.8 Serial Port

This section allows you to set the serial port parameters. R5020 Router supports one COM1 and one COM2, also can be configured as either two COM1 or two COM2. Serial port provides a way to transfer serial data to IP data, or vice versa, and transmit these data via wired or wireless network to achieve data transparent transmission.

Seria	l Port	Statu	s	
^ Seria	l Port Set	ttings		
Index	Port	Enable	Baud Rate	Application Mode
1	COM1	false	115200	Transparent
2	COM2	false	115200	Transparent

Click the edit button of COM1.

Serial Port					
Serial Port Application Settings					
Index	1				
Port	COM1 V				
Enable	ON OFF				
Baud Rate	115200 V				
Data Bits	8				
Stop Bits	1 v				
Parity	None				
Flow Control	None				
∧ Data Packing					
Packing Timeout	50 🥱				
Packing Length	1200				



The window is displayed as below when choosing "Transparent" as the application mode and "TCP Client" as the protocol.

∧ Server Setting	
Application Mode	Transparent v
Protocol	TCP Client v
Server Address	
Server Port	

The window is displayed as below when choosing "Transparent" as the application mode and "TCP Server" as the protocol.

∧ Server Setting	
Application Mode	Transparent v
Protocol	TCP Server v
Local IP	
Local Port	

The window is displayed as below when choosing "Transparent" as the application mode and "UDP" as the protocol.

∧ Server Setting	
Application Mode	Transparent v
Protocol	UDP v
Local IP	
Local Port	
Server Address	
Server Port	

The window is displayed as below when choosing "Modbus RTU Router" as the application mode and "TCP Client" as the protocol.

∧ Server Setting	
Application Mode	Modbus RTU Gatewa v
Protocol	TCP Client v
Server Address	
Server Port	



The window is displayed as below when choosing "Modbus RTU Router" as the application mode and "TCP Server" as the protocol.

∧ Server Setting	
Application Mode	Modbus RTU Gatewa v
Protocol	TCP Server v
Local IP	
Local Port	

The window is displayed as below when choosing "Modbus RTU Router" as the application mode and "UDP" as the protocol.

∧ Server Setting	
Application Mode	Modbus RTU Gatewa v
Protocol	UDP
Local IP	
Local Port	
Server Address	
Server Port	

The window is displayed as below when choosing "Modbus ASCII Router" as the application mode and "TCP Client" as the protocol.

∧ Server Setting	
Application Mode	Modbus ASCII Gatev v
Protocol	TCP Client v
Server Address	
Server Port	

The window is displayed as below when choosing "Modbus ASCII Router" as the application mode and "TCP Server" as the protocol.

∧ Server Setting	
Application Mode	Modbus ASCII Gatev v
Protocol	TCP Server v
Local IP	
Local Port	



The window is displayed as below when choosing "Modbus ASCII Router" as the application mode and "UDP" as the protocol.

∧ Server Setting	
Application Mode	Modbus ASCII Gatev v
Protocol	UDP
Local IP	
Local Port	
Server Address	
Server Port	

Serial Port					
Item	Description	Default			
	Serial Port Application Settings				
Index	Indicate the ordinal of the list.				
Port	Show the current serial's name, read only.	COM1			
Enable	Click the toggle button to enable/disable this serial port. When the status is OFF, the serial port is not available.	OFF			
Baud Rate	Select from "300", "600", "1200", "2400", "4800", "9600", "19200", "38400", "57600" , "115200" or "230400".	115200			
Data Bits	Select from "7" or "8".	8			
Stop Bits	Select from "1" or "2".	1			
Parity	Select from "None", "Odd" or "Even".	None			
Flow control	Select from "None", "Software" or "Hardware".	None			
	Data Packing				
Packing Timeout	Set the packing timeout. The serial port will queue the data in the buffer and	50			
	send the data to the Cellular WAN/Ethernet WAN when it reaches the Interval				
	Timeout in the field.				
	Note: Data will also be sent as specified by the packet length even when data is				
	not reaching the interval timeout in the field.				
Packing Length	Set the packet length. The Packet length setting refers to the maximum amount	1200			
	of data that is allowed to accumulate in the serial port buffer before sending.				
	When a packet length between 1 and 3000 bytes is specified, data in the buffer				
	will be sent as soon it reaches the specified length.				

Server Settings				
Item	Description	Default		
Application Mode	 Select from "Transparent", "Modbus RTU Router" or "Modbus ASCII Router". Transparent: Router will transmit the serial data transparently Modbus RTU Router: Router will translate the Modbus RTU data to Modbus TCP data and sent out, and vice versa 	Transparent		



Server Settings				
Item	Description	Default		
	Modbus ASCII Router: Router will translate the Modbus ASCII			
	data to Modbus TCP data and sent out, and vice versa			
Protocol	Select from "TCP Client", "TCP Server", "UDP" or "Robustlink".	TCP Client		
	• TCP Client: Router works as TCP client, initiate TCP			
	connection to TCP server. Server address supports both IP			
	and domain name			
	• TCP Server: Router works as TCP server, listening for			
	connection request from TCP client			
	UDP: Router works as UDP client			
	Robustlink: Router will automatically upload the serial data			
	to Robustlink platform under the Robustlink protocol.			
	Robustlink is a management platform from Robustel. This			
	function only available when Router is connects to			
	Robustlink			
Server Address	Enter the address of server which will receive the data sent from	Null		
	router's serial port. IP address or domain name will be available.			
Server Port	Enter the specified port of server which is used for receiving the	Null		
	serial data.			
Local IP @ Transparent	Enter router's LAN IP which will forward to the internet port of	Null		
	router.			
Local Port @	Enter the port of router's LAN IP.	Null		
Transparent				
Local IP @ Modbus	Enter the local IP of under Modbus mode.	Null		
Local Port @ Modbus	Enter the local port of under Modbus mode.	Null		

Click the "Status" column to view the current serial port type.

Serial P	ort	Status			
∧ Serial I	Port Stati	us list			
Index	Туре	тх	RX	Connection Status	
1	RS232	0B	0B		
2	RS485	0B	0B		

4.3 Network

4.3.1 Route

This section allows you to set the static route. Static routes, based on the destination address, can add up to 20 static routes to the router.

Click **Network > Routing > Static Routing** to enter the static routing table, which allows users to manually add, delete or modify static routing rules.



Static R	toute	Status				
∧ Static	Route Table					
Index	Description	Destination	Netmask	Gateway	Interface	+

Click + to add static route. The maximum count is 20.

Static Route	
∧ Static Route	
Index	1
Description	
Destination	
Netmask	
Gateway	
Interface	wwan

Static Route				
Item	Description	Default		
Index	Indicate the ordinal of the list.			
Description	Enter a description for this route.	Null		
Destination	Enter the IP address of destination host or destination network.	Null		
Netmask	Enter the Netmask of destination host or destination network.	Null		
Router	Define the router of the destination.	Null		
Interface	Choose the corresponding port of the link that you want to configure.	wwan		

This window allows you to view the status of route.

Static Ro	ute Sta	atus				
A Route T	able					
Index	Destination	Netmask	Gateway	Interface	Metric	
1	0.0.0.0	0.0.0.0	10.122.74.9	wwan	0	
2	10.122.74.8	255.255.255.248	0.0.0.0	wwan	0	
3	172.16.0.0	255.255.0.0	0.0.0.0	lan0	0	

4.3.2 Firewall

This section is used to set firewall parameters, including setting access control and adding filtering rules. Filtering rules allow users to customize to accept or discard specified access sources and filter their IP addresses or MAC addresses.

Click **Network > Firewall > Filtering** to display the following.



~ Whit	telist Rules						?
Index	Descript	ion So	urce Address				+
∧ Filte	ring Rules						
Index	Source Address	Source Port	Source MAC	Target Address	Target Port	Protocol	+

Click + to add whitelist rules. The maximum count is 50.

Filtering	
∧ Whitelist Rules	
Index	1
Description	
Source Address	





Click + to add filtering rules. The maximum count is 50. The window is displayed as below when defaulting "All" or choosing "ICMP" as the protocol. Here take "All" as an example.

Filtering	
∧ Filtering Rules	
Index	1
Description	
Source Address	0
Source MAC	0
Target Address	0
Protocol	All
Action	Drop

The window is displayed as below when choosing "TCP", "UDP" or "TCP-UDP" as the protocol. Here take "TCP" as an example.

∧ Filtering Rules	
Index	1
Description	
Source Address	0
Source Port	0
Source MAC	0
Target Address	0
Target Port	
Protocol	ТСР
Action	Drop

Filtering				
Item	Description	Default		
	General Settings			
Enable Filtering	Click the toggle button to enable/disable the filtering option.	ON		
Default Filtering Policy	 Select from "Accept" or "Drop". Cannot be changed when filtering rules table is not empty. Accept: Router will accept all the connecting requests except the hosts which fit the drop filter list Drop: Router will drop all the connecting requests except the hosts which fit the accept filter list 			
Access Control Settings				
Enable Remote SSH Access	Click the toggle button to enable/disable this option. When enabled, the Internet user can access the router remotely via SSH.	OFF		



	Filtering	
Item	Description	Default
Enable Local SSH Access	Click the toggle button to enable/disable this option. When enabled,	ON
	the LAN user can access the router locally via SSH.	
Enable Remote Telnet Access	Click the toggle button to enable/disable this option. When enabled,	OFF
	the Internet user can access the router remotely via Telnet.	
Enable Local Telnet Access	Click the toggle button to enable/disable this option. When enabled,	ON
	the LAN user can access the router locally via Telnet.	
Enable Remote HTTP Access	Click the toggle button to enable/disable this option. When enabled,	OFF
	the Internet user can access the router remotely via HTTP.	
Enable Local HTTP Access	Click the toggle button to enable/disable this option. When enabled,	ON
	the LAN user can access the router locally via HTTP.	
Enable Remote HTTPS Access	Click the toggle button to enable/disable this option. When enabled,	ON
	the Internet user can access the router remotely via HTTPS.	
Enable Remote Ping Respond	Click the toggle button to enable/disable this option. When enabled,	ON
	the router will reply to the Ping requests from other hosts on the	
	Internet.	
Enable DOS Defending	Click the toggle button to enable/disable this option. When enabled,	ON
	the router will defend the DOS. Dos attack is an attempt to make a	
	machine or network resource unavailable to its intended users.	
Enable Console	Click the toggle button to enable/disable this option. When enabled,	ON
	the user can access the router via Console.	
Enable the vpn_nat traversal	Click the toggle button to enable/disable this option. When enabled,	OFF
	the router automatically modifies the IP address of the VPN header	
	received by WAN/WWAN to the IP address of the device under LAN	
	port and sends it out.	
	Whitelist Rules	
Item	Description	Default
Index	Indicate the ordinal of the list.	
Description	Enter a description for this whitelist rule.	Null
Source Address	Defines if access is allowed from one or a range of IP addresses which	Null
	are defined by Source IP Address, or every IP addresses.	
	Filtering Rules	
Index	Indicate the ordinal of the list.	
Description	Enter a description for this filtering rule.	Null
Source Address	Defines if access is allowed from one or a range of IP addresses which	Null
	are defined by Source IP Address, or every IP addresses.	
Source Port	Specify an access originator and enter its source port.	Null
Source MAC	Enter the MAC address of the defined source IP address.	Null
Target Address	Defines if access is allowed to one or a range of IP addresses which are	Null
	defined by Target IP Address, or every IP addresses.	
Target Port	Enter the target port which the access originator wants to access.	Null
Protocol	Select from "All", "TCP", "UDP", "ICMP" or "TCP-UDP".	All
		1
	Note : It is recommended that you choose "All" if you don't know	



Filtering					
Item	Description	Default			
Action	Select from "Accept" or "Drop".	Drop			
	• Accept: When Default Filtering Policy is drop, router will drop all				
	the connecting requests except the hosts which fit this accept				
	filtering list				
	• Drop: When Default Filtering Policy is accept, router will accept all				
	the connecting requests except the hosts which fit this drop				
	filtering list				

Port mapping is defined manually in routers, and all data received from certain ports of the public network is forwarded to a certain port of an IP in the intranet. Click **Network > Firewall > Port Mapping** to display as follows:

Filterin	g F	Port Mapping	Custom Rules		DMZ	Status	
∧ Port Ma	pping Rule	25					
Index	Description	Internet Port	Local IP	Local Port	Protoco	I	+

Click + to add port mapping rules. The maximum rule count is 50.

Port Mapping	
∧ Port Mapping Rules	
Index	1
Description	
Remote IP	0
Internet Port	0
Local IP	
Local Port	0
Protocol	TCP-UDP V

Port Mapping Rules					
Item	Description				
Index	Indicate the ordinal of the list.				
Description	Enter a description for this port mapping.	Null			
Remote IP	pecify the host or network which can access to the local IP address. Null				
	Empty means unlimited. e.g. 10.10.10.10/255.255.255.255 or 192.168.1.0/24				
Internet Port	Set the internet port of router which can be accessed by other hosts from Null internet.				
Local IP	Enter router's LAN IP which will forward to the internet port of router. Null				
Local Port	Enter the port of router's LAN IP. Null				
Protocol	Select from "TCP", "UDP" or "TCP-UDP" as your application required.	TCP-UDP			

"Custom Rules" is user-defined rules. Click "Network > Firewall > Custom Rules" to display the following.

Filtering	Port Mapping	Custom Rules	DMZ	Status			
∧ Custom Iptab	∧ Custom Iptables Rules						
Index Descrip	otion Rule				+		
Click 🕂 to add cu	stom rules. The ma	ximum rule count is	50.				
Custom Rules							
∧ Custom Iptables Rule							

1

Index

Rule

Description

Custom Iptables Rules				
Item	Description	Default		
Index	Indicate the ordinal of the list.			
Description	Enter a description for this custom rule.	Null		
Rule	Specify one custom rule.	Null		

?

DMZ (Demilitarized Zone), namely the isolation zone, also known as the demilitarized zone. It is a buffer between a non-security system and a security system in order to solve the problem that the access users of the external network cannot access the internal network server after installing the firewall. The DMZ host is an intranet host that has open access to all ports except those occupied and forwarded.

Click "Network > Firewall > DMZ" to display as follows:

Filtering	Port Mapping	Custom Rules	DMZ	Status
∧ DMZ Settings				
	Er	nable DMZ	F	
	Host I	P Address		
	Source I	P Address	?	

	DMZ Settings				
Item	Item Description				
Enable DMZ	Click the toggle button to enable/disable DMZ. DMZ host is a host on the OFF				
	internal network that has all ports exposed, except those ports otherwise				
	forwarded.				
Host IP Address	Enter the IP address of the DMZ host on your internal network.	Null			
Source IP Address	Set the address which can talk to the DMZ host. 0.0.0.0 means for any Null				
	addresses.				

This window allows you to view the status of chain input, chain forward and chain output.

Filteri	ng	Port Map	ping	Custom Ru	les	DMZ	Status
∧ Chain	Input						
Index	Packets	Target	Protocol	In	Out	Source	Destination
1	0	DROP	tcp	wwan	*	0.0.0/0	0.0.0/0
2	0	DROP	tcp	wwan	*	0.0.0/0	0.0.0/0
3	0	DROP	tcp	wwan	*	0.0.0/0	0.0.0/0
4	0	REJECT	tcp	*	*	0.0.0/0	0.0.0/0
5	52	ACCEPT	tcp	*	*	0.0.0/0	0.0.0/0
6	0	DROP	tcp	*	*	0.0.0/0	0.0.0/0
7	0	ACCEPT	tcp	-	*	0.0.0/0	0.0.0/0
8	0	DROP	tcp	*	*	0.0.0/0	0.0.0/0
9	0	ACCEPT	icmp	*	*	0.0.0/0	0.0.0/0
10	0	DROP	icmp	*	*	0.0.0/0	0.0.0/0
∧ Chain	Forward						
Index	Packets	Target	Protocol	In	Out	Source	Destination
1	0	TCPMSS	tcp	*	*	0.0.0/0	0.0.0/0
∧ Chain Output							
Index	Packets	Target	Protocol	In	Out	Source	Destination

4.3.3 IP Passthrough

Click Network > IP Passthrough > IP Passthrough to enable or disable the IP Pass-through option.

IP Passthrough		
∧ General Settir	ngs	
	Enable	ON OFF

If router enables the IP Pass-through, the terminal device (such as PC) will enable the DHCP Client mode and connect to LAN port of the router; and after the router dial up successfully, the PC will automatically obtain the IP address and DNS server address which assigned by ISP. To use this feature, the primary link needs to be set to WWAN and the backup link needs to be set to None.

4.4 VPN

4.4.1 IPsec

IPsec (Internet Protocol Security) is a protocol built on the Internet Protocol layer that enables two hosts to communicate in a secure manner. IPsec is the direction of secure networking and provides proactive protection against attacks on private networks and the Internet through end-to-end security. Click Virtual Private Network > IPsec > General to set IPsec parameters

12 robuste



General	Tunnel	Stat	us	x509		
∧ General Setti	ngs					
		Keepalive	20		?	
	Optimize DH Exp	onent Size	ON OF	FF 😨		
	Del	bug Enable	ON OF	FF		

General Settings @ General				
Item	Description	Default		
Keepalive	Set the keepalive time, measured in seconds. The router will send packets	20		
	to NAT server every keepalive time to avoid record remove from the NAT			
	list.			
Optimize DH Exponent	Click the toggle button to enable/disable this option. When enabled, it	OFF		
Size	reduces the time to generate the key			
Debug Enable	Click the toggle button to enable/disable this option. Enable for IPsec VPN	OFF		
	information output to the debug port.			

Genera	al	Tunnel	Statu	IS	x5	09	
∧ Tunnel	Settings						
Index	Enable	Description	Gateway	Loc	al Subnet	Remote Subnet	+

Click + to add tunnel settings. The maximum count is 6.

Tunnel	
∧ General Settings	
Index	1
Enable	ON OFF
Description	
Gateway	
Mode	Tunnel
Protocol	ESP
Local Subnet	
Remote Subnet	

General Settings @ Tunnel				
Item	Description	Default		
Index	Indicate the ordinal of the list.			
Enable	Click the toggle button to enable/disable this IPsec tunnel.	ON		
Description	Enter a description for this IPsec tunnel.	Null		
Router	Enter the address of remote side IPsec VPN server. 0.0.0.0 represents for any	Null		
	address.			



Mode	Select from "Tunnel" and "Transport".	Tunnel
	• Tunnel: Commonly used between routers, or at an end-station to a router,	
	the router acting as a proxy for the hosts behind it	
	 Transport: Used between end-stations or between an end-station and a 	
	router, if the router is being treated as a host-for example, an encrypted	
	Telnet session from a workstation to a router, in which the router is the	
	actual destination	
Protocol	Select the security protocols from "ESP" and "AH".	ESP
	• ESP: Use the ESP protocol	
	AH: Use the AH protocol	
Local Subnet	Enter the local subnet's address with mask protected by IPsec, e.g.	Null
	192.168.1.0/24	
Remote Subnet	Enter the remote subnet's address with mask protected by IPsec, e.g. 10.8.0.0/24	Null
Link binding	Select the link to build IPsec.	Unbound

The window is displayed as below when choosing "PSK" as the authentication type.

∧ IKE Settings	
ІКЕ Туре	IKEv1 v
Negotiation Mode	Main
Authentication Algorithm	MD5
Encryption Algorithm	3DES v
IKE DH Group	DHgroup2 v
Authentication Type	PSK
PSK Secret	
Local ID Type	Default
Remote ID Type	Default
IKE Lifetime	86400

The window is displayed as below when choosing "CA" as the authentication type.

∧ IKE Settings	
ІКЕ Туре	IKEv1 v
Negotiation Mode	Main
Authentication Algorithm	MD5
Encryption Algorithm	3DES v
IKE DH Group	DHgroup2 v
Authentication Type	CA
Private Key Password	
IKE Lifetime	86400



The window is displayed as below when choosing "PCKS#12" as the authentication type.

∧ IKE Settings	
ІКЕ Туре	IKEv1 v
Negotiation Mode	Main
Encryption Algorithm	3DES v
Authentication Algorithm	SHA1 v
IKE DH Group	DHgroup2 v
Authentication Type	PKCS#12
Private Key Password	
IKE Lifetime	86400

The window is displayed as below when choosing "xAuth PSK" as the authentication type.

∧ IKE Settings	
ІКЕ Туре	IKEv1 v
Negotiation Mode	Main
Authentication Algorithm	MD5
Encryption Algorithm	3DES v
IKE DH Group	DHgroup2
Authentication Type	xAuth PSK v
PSK Secret	
Local ID Type	Default
Remote ID Type	Default
Username	
Password	
IKE Lifetime	86400



The window is displayed as below when choosing "xAuth CA" as the authentication type.

∧ IKE Settings	
ІКЕ Туре	IKEv1 v
Negotiation Mode	Main
Authentication Algorithm	MD5
Encryption Algorithm	3DES v
IKE DH Group	DHgroup2 v
Authentication Type	xAuth CA v
Private Key Password	
Username	
Password	
IKE Lifetime	86400

	IKE Settings			
Item	Description	Default		
ІКЕ Туре	Select from "IKEv1" and "IKEv2".	IKEv1		
Negotiation Mode	Select from "Main" and "Aggressive" for the IKE negotiation mode in phase 1.	Main		
	If the IP address of one end of an IPsec tunnel is obtained dynamically, the IKE			
	negotiation mode must be aggressive. In this case, SAs can be established as			
	long as the username and password are correct.			
Authentication	Select from "MD5", "SHA1", "SHA2 256" or "SHA2 512" to be used in IKE	MD5		
Algorithm	negotiation.			
Encrypt Algorithm	Select from "3DES", "AES128", "AES192" and "AES256" to be used in IKE	3DES		
	negotiation.			
	3DES: Use 168-bit 3DES encryption algorithm in CBC mode			
	AES128: Use 128-bit AES encryption algorithm in CBC mode			
	AES128: Use 192-bit AES encryption algorithm in CBC mode			
	AES256: Use 256-bit AES encryption algorithm in CBC mode			
IKE DH Group	Select from "DHgroup1", "DHgroup2", "DHgroup5", "DHgroup14",	DHgroup2		
	"DHgroup15", "DHgroup16", "DHgroup17" or "DHgroup18" to be used in key			
	negotiation phase 1.			
Authentication Type	Select from "PSK", "CA", "xAuth PSK" and "xAuth CA" to be used in IKE	PSK		
	negotiation.			
	PSK: Pre-shared Key			
	CA: Certification Authority			
	xAuth: Extended Authentication to AAA server			
PSK Secret	Enter the pre-shared key.	Null		
Local ID Type	Select from "Default", "FQDN" and "User FQDN" for IKE negotiation.	Default		
	Default: Uses an IP address as the ID in IKE negotiation			
	• FQDN: Uses an FQDN type as the ID in IKE negotiation. If this option is			
	selected, type a name without any at sign (@) for the local security			
	router, e.g., test.robustel.com			



IKE Settings				
Item	Description			
	 User FQDN: Uses a user FQDN type as the ID in IKE negotiation. If this option is selected, type a name string with a sign "@" for the local security router, e.g., test@robustel.com 			
Remote ID Type	 Select from "Default", "FQDN" and "User FQDN" for IKE negotiation. Default: Uses an IP address as the ID in IKE negotiation FQDN: Uses an FQDN type as the ID in IKE negotiation. If this option is selected, type a name without any at sign (@) for the local security router, e.g., test.robustel.com User FQDN: Uses a user FQDN type as the ID in IKE negotiation. If this option is selected, type a name string with a sign "@" for the local security router, e.g., test@robustel.com 			
IKE Lifetime	Set the lifetime in IKE negotiation. Before an SA expires, IKE negotiates a new86400SA. As soon as the new SA is set up, it takes effect immediately and the oldone will be cleared automatically when it expires.			
Private Key Password	Enter the private key under the "CA" and "xAuth CA" authentication types. Null			
Username	Enter the username used for the "xAuth PSK" and "xAuth CA" authentication Null types.			
Password	Enter the password used for the "xAuth PSK" and "xAuth CA" authentication Null sypes.			

If click **VPN > IPsec > Tunnel > General Settings**, and choose **ESP** as protocol. The specific parameter configuration is shown as below.

Tunnel	
∧ General Settings	
Index	1
Enable	ON OFF
Description	
Gateway	
Mode	Tunnel
Protocol	ESP
Local Subnet	
Remote Subnet	
Link Binding	Unspecified 🗸
✓ IKE Settings	



∧ SA Settings	
Encrypt Algorithm	3DES V
Authentication Algorithm	MD5 V
PFS Group	DHgroup2
SA Lifetime	28800 🦻
DPD Interval	60 🤇
DPD Failures	180 🦻

If choose AH as protocol, the window of SA Settings is displayed as below.

∧ General Settings	
Index	1
Enable	ON OFF
Description	
Gateway	
Mode	Tunnel
Protocol	AH
Local Subnet	
Remote Subnet	
∧ SA Settings	
Authentication Algorithm	SHA1 v
PFS Group	DHgroup2 v
SA Lifetime	28800
DPD Interval	30 🦻
DPD Failures	150 🥱
▲ Advanced Settings	150 🧿
	150 ?
Advanced Settings	

SA Settings				
Item Description De				
Encrypt Algorithm	Select from "3DES", "AES128", "AES192" or "AES256" when you select "ESP"	3DES		
	in "Protocol". Higher security means more complex implementation and			
	lower speed. DES is enough to meet general requirements. Use 3DES when			
	high confidentiality and security are required.			
Authentication	Select from "MD5", "SHA1", "SHA2 256" or "SHA2 512" to be used in SA	MD5		
Algorithm	negotiation.			



SA Settings			
Item	Description	Default	
PFS Group	Select from "PFS (N/A)", "DHgroup1", "DHgroup2", "DHgroup5",	DHgroup2	
	"DHgroup14", "DHgroup15", "DHgroup16", "DHgroup17" or "DHgroup18"		
	to be used in SA negotiation.		
SA Lifetime	Set the IPsec SA lifetime. When negotiating to set up IPsec SAs, IKE uses the	28800	
	smaller one between the lifetime set locally and the lifetime proposed by		
	the peer.		
DPD Interval	Set the interval after which DPD is triggered if no IPsec protected packets is	30	
	received from the peer. DPD is a Dead peer detection. DPD irregularly		
	detects dead IKE peers. When the local end sends an IPsec packet, DPD		
	checks the time the last IPsec packet was received from the peer. If the time		
	exceeds the DPD interval, it sends a DPD hello to the peer. If the local end		
	receives no DPD acknowledgment within the DPD packet retransmission		
	interval, it retransmits the DPD hello. If the local end still receives no DPD		
	acknowledgment after having made the maximum number of		
	retransmission attempts, it considers the peer already dead, and clears the		
	IKE SA and the IPsec SAs based on the IKE SA.		
DPD Failures	Set the timeout of DPD (Dead Peer Detection) packets.	150	
	Advanced Settings		
Enable Compression	Click the toggle button to enable/disable this option. Enable to compress	OFF	
	the inner headers of IP packets.		
Enable Forceencaps	Click the toggle button to enable/disable this option. When enabled, UDP	OFF	
	encapsulation of esp packets is forced even if NAT conditions are not		
	detected. This helps overcome restrictive firewalls.		
Expert Options	Add more PPP configuration options here, format: config-desc;config-desc,	Null	
	e.g. protostack=netkey;plutodebug=none		

This section allows you to view the status of the IPsec tunnel.

General		Tunnel	Status	x509	
∧ IPSec Tun	nel Status	;			
Index De	scription	Status	Uptime		

User can upload the X509 certificates for the IPsec tunnel in this section.

General	Τι	innel	Statu	IS	x509	
^ X509 Set	tings					?
		Tur	nnel Name	Tunnel 1	×	
		Local	Certificate	Choose F	ile No file chosen	
		Remote	Certificate	Choose F	ile No file chosen	
		P	rivate Key	Choose F	ile No file chosen	
	-1					
Certificat	e Files					
Index	File Name		File Size	9	Modification Ti	me



x509				
Item	tem Description			
	X509 Settings			
Tunnel Name	Choose a valid tunnel from "tunnel 1", "tunnel 2", "tunnel 3", "tunnel 4",	Tunnel 1		
	"tunnel 5" and "tunnel 6".			
Local Certificate	Click on "Choose File" to locate the certificate file from local computer, and			
	then import this file into your router.			
Remote Certificate	Click on "Choose File" to locate the certificate file from remote computer,			
	and then import this file into your router.			
Private Key	Click on "Choose File" to locate the private key file from local computer, and			
	then import this file into your router.			
CA certificate	Click on "Choose File" to locate the private key file from local computer, and			
	then import CA certificate into your router.			
PKCS#12 Certificate	Click on "Choose File" to locate the private key file from local computer, and			
	then import PKCS#12 certificate into your router.			
Certificate Files				
Index	Indicate the ordinal of the list.			
Filename	Show the imported certificate's name.	Null		
File Size	Show the size of the certificate file.	Null		
Modification Time	Show the timestamp of that the last time to modify the certificate file.	Null		

4.4.2 OpenVPN

This section allows you to set the OpenVPN and the related parameters. OpenVPN, an open source SSL-based VPN system. The OpenVPN feature can support both point-to-point and point-to-multipoint (client-side) VPN channels. Click "VPN > OpenVPN > OpenVPN" to display the following.

OpenVPI	N	Status	x509		
^ Tunnel Settings					
Index	Enable	Description M	ode		+
∧ Password Manage					
Index Username +					
∧ Client Manage					
Index	Enable	Common Name	Client IP Address		+

Click to add tunnel settings. The maximum count is 5. The window is displayed as below when choosing "P2P" as the mode.



∧ General Settings	
Index	1
Enable	ON OFF
Description	
Mode	P2P v
Protocol	UDP
Server Address	
Server Port	1194
Interface Type	TUN
Authentication Type	None v 🦻
Local IP	10.8.0.1
Remote IP	10.8.0.2
Keepalive Interval	20
Keepalive Timeout	120
Enable Compression	ON OFF
Enable NAT	ON OFF
Verbose Level	0 2

The window is displayed as below when choosing "Auto" as the mode.

OpenVPN	
∧ General Settings	
Index	1
Enable	ON OFF
Description	
Mode	Auto 🧹 🧭
Private Key Password	
Enable Client Status	Off OFF
Enable NAT	OM OFF



The window is displayed as below when choosing "Client" as the mode.

∧ General Settings	
Index	1
Enable	ON OFF
Description	
Mode	Client
Protocol	UDP
Server Address	
Server Port	1194
Interface Type	TUN
Authentication Type	None v 🤊
Renegotiation Interval	86400
Keepalive Interval	20
Keepalive Timeout	120
Enable Compression	ON OT
Enable NAT	OS OFF
Verbose Level	0 2



The window is displayed as below when choosing "Server" as the mode.

∧ General Settings	
Index	1
Enable	ON OFF
Description	
Mode	Server v
Protocol	UDP
Listen IP Address	
Listen Port	1194
Interface Type	TUN
Authentication Type	None v
Enable IP Pool	ON OFF
Client Subnet	10.8.0.0
Client Subnet Netmask	255.255.255.0
Renegotiation Interval	86400
Max Clients	10
Keepalive Interval	20
Keepalive Timeout	120
τυν μτυ	1500
Max Frame Size	
Enable Compression	ON OFF
Enable Default Gateway	ON OFF
Enable NAT	ON OFF
Verbose Level	



The window displays as follows when "None" is selected as the authentication type.



The window displays as follows when "Preshared" is selected as the authentication type.

∧ General Settings	
Index	1
Enable	ON OFF
Description	
Mode	Client v
Protocol	UDP
Peer Address	
Peer Port	1194
Interface Type	TUN
Authentication Type	Preshared 🦳
Encrypt Algorithm	BF
Authentication Algorithm	SHA1 V
Renegotiation Interval	86400
Keepalive Interval	20
Keepalive Timeout	120
τυν μτυ	1500
Max Frame Size	
Enable Compression	ON OFF
Enable NAT	ON OFF
Enable DNS overrid	ON OFF ?
Verbose Level	0 v



The window displays as follows when "Password" is selected as the authentication type.

∧ General Settings	
Index	1
Enable	ON OFF
Description	
Mode	Client 🤍 🍞
Protocol	UDP
Peer Address	
Peer Port	1194
Interface Type	
Authentication Type	Password v 🦻
Username	
Password	
Encrypt Algorithm	BF
Authentication Algorithm	SHA1 v
Renegotiation Interval	86400
Keepalive Interval	20
Keepalive Timeout	120
τυν μτυ	1500
Max Frame Size	
Enable Compression	ON OFF
Enable NAT	ON OFF
Enable DNS overrid	ON OFF ?
Verbose Level	



The window displays as follows when "X509CA" is selected as the authentication type.

∧ General Settings	,,
Index	1
Enable	ON OFF
Description	
Mode	Client 🤍 🥱
Protocol	UDP
Peer Address	
Peer Port	1194
Interface Type	TUN
Authentication Type	X509CA 7
Encrypt Algorithm	BF
Authentication Algorithm	SHA1
Renegotiation Interval	86400
Keepalive Interval	20
Keepalive Timeout	120
τυν μτυ	1500
Max Frame Size	
Private Key Password	
ΡΓΙνατε κεγ Ρασσωσια	
Enable Compression	ON OFF
Enable NAT	ON OFF
Enable DNS overrid	ON OFF 😨
Verbose Level	
	_ ~



The window displays as follows when "X509CA Pssword" is selected as the authentication type.

∧ General Settings	
Index	1
Enable	ON OFF
Description	
Mode	Client v 🕝
Protocol	UDP
Peer Address	
Peer Port	1194
Interface Type	TUN
Authentication Type	X509CA Password 🗸 🦻
Username	
Password	
Encrypt Algorithm	BF
Authentication Algorithm	SHA1 v
Renegotiation Interval	86400 🝞
Keepalive Interval	20
Keepalive Timeout	120 🥱
τυν μτυ	1500
Max Frame Size	
Private Key Password	
Enable Compression	ON OFF
Enable NAT	ON OFF
Enable DNS overrid	ON OFF ?
Verbose Level	0 v 🦻

General Settings @ OpenVPN		
Item	Description	Default
Index	Indicate the ordinal of the list.	
Enable	Click the toggle button to enable/disable this OpenVPN tunnel.	ON
Description	Enter a description for this OpenVPN tunnel.	Null
Mode	Select from "P2P" or "Client".	Client
Protocol	Select from "UDP", "TCP-Client" or "TCP-Server".	UDP
Server Address	Enter the end-to-end IP address or the domain of the remote OpenVPN server.	Null
Server Port	Enter the end-to-end listener port or the listener port of the OpenVPN server.	1194
Listen IP Address	Enter the IP address or domain name of this end.	Null



	General Settings @ OpenVPN	
Item	Description	Default
Listen Port	Enter the listening port of this end.	1194
Interface Type	Select from "TUN", "TAP" which are two different kinds of device	TUN
	interface for OpenVPN. The difference between TUN and TAP device is	
	that a TUN device is a point-to-point virtual device on network while a	
	TAP device is a virtual device on Ethernet.	
Username	Enter the username used for "Password" or "X509CA Password"	Null
	authentication type.	
Password	Enter the password used for "Password" or "X509CA Password"	Null
	authentication type.	
Authentication Type	Select from "None", "Preshared", "Password", "X509CA" and "X509CA	None
	Password".	
	Note: "None" and "Preshared" authentication type are only working	
	with P2P mode.	
Enable IP Pool	Click the toggle button to enable/disable this option. When enabled, the	OFF
	client will get the virtual IP from the address pool.	
Local IP	Enter the local virtual IP.	10.8.0.1
Remote IP	Enter the remote virtual IP.	10.8.0.2
Client Subnet	The client virtual IP network address.	10.8.0.0
Client Subnet	The client virtual IP network address mask.	255.255.255.0
Netmask		2001200120010
Encrypt Algorithm	Select from "BF", "DES", "DES-EDE3", "AES128", "AES192" and	BF
	"AES256".	
	 BF: Use 128-bit BF encryption algorithm in CBC mode 	
	 DES: Use 64-bit DES encryption algorithm in CBC mode 	
	 DES-EDE3: Use 192-bit 3DES encryption algorithm in CBC mode 	
	 AES128: Use 128-bit AES encryption algorithm in CBC mode 	
	 AES192: Use 192-bit AES encryption algorithm in CBC mode 	
	AES256: Use 256-bit AES encryption algorithm in CBC mode	
Authentication	Choose from "MD5", "SHA1", "SHA256" and "SHA512".	SHA1
Algorithm		
Max Clients	Set the maximum number of client connections in server mode.	10
Renegotiation	Set the renegotiation interval. If connection failed, OpenVPN will	86400
Interval	renegotiate when the renegotiation interval reached.	00100
Keepalive Interval	Set keepalive (ping) interval to check if the tunnel is active.	20
Keepalive Timeout	Set the keepalive timeout. Trigger OpenVPN restart after n seconds pass	120
Reepaire mileout	without reception of a ping or other packet from remote.	120
TUN MTU	Set the MTU of tunnel.	1500
Max Frame Size	Set the slice size of the data to be transferred in the tunnel.	Null
		Null
Private Key Password	Enter the private key password under the "X509CA" and "X509CA Password" authentication type	INUII
Enable Compression	Password" authentication type.	
Enable Compression	Click the toggle button to enable/disable this option. Enable to	ON
	compress the data stream of the header.	



General Settings @ OpenVPN				
Item	Description	Default		
Enable DNS overrid	Click the toggle button to enable/disable this option. When enabled, the	OFF		
	DNS pushed by the server will be received as the local DNS server.			
Enable Default	Click the toggle button to enable/disable this option. When enabled, the	ON		
Gateway	gateway pushed by the server will be received as the local gateway.			
Enable Client Status	Click the toggle button to enable/disable this option. Used to display	OFF		
	information about the status of connected clients when the server is			
	enabled.			
Enable NAT	Click the toggle button to enable/disable the NAT option. When	OFF		
	enabled, the source IP address of host behind router will be disguised			
	before accessing the remote OpenVPN client.			
Verbose Level	Select the level of the output log and values from 0 to 11.	0		
	O: No output except fatal errors			
	1~4: Normal usage range			
	• 5: Output R and W characters to the console for each packet read			
	and write			
	6~11: Debug info range			

Advanced Settings @ OpenVPN		
Item	Description	Default
Enable HMAC Firewall	Click the toggle button to enable/disable this option. Add an additional	OFF
	layer of HMAC authentication on top of the TLS control channel to protect	
	against DoS attacks.	
Enable PKCS#12	Click the toggle button to enable/disable the PKCS#12 certificate. It is an	OFF
	exchange of digital certificate encryption standard, used to describe	
	personal identity information.	
Enable nsCertType	Click the toggle button to enable/disable nsCertType. Require that peer	OFF
	certificate was signed with an explicit nsCertType designation of "server".	
Expert Options	Enter some other options of OpenVPN in this field. Each expression can be	Null
	separated by a ';'.	

Click Password Manage 🕂 to add user names and passwords, up to 20. The following is displayed.

OpenVPN		Alassa.	
∧ General Settings			
Index	1		
Username			
Password			
		Submit	Close



Password Manage					
Item	Description	Default			
General Settings					
Index	Indicate the ordinal of the list				
Username	In server mode, configure the username of the client. Null				
Password In server mode, configure the password corresponding to the user name of the client.		Null			

Click Password Manage 🕂 to add user names and passwords, up to 20. The following is displayed.

OpenVPN	
∧ General Settings	
Index	1
Enable	ON OFF
Common Name	
Client IP Address	

OpenVPN				
Item	Description	Default		
General Settings				
Index	Indicate the ordinal of the list.			
Enable	Click the toggle button to enable/disable this option. ON			
Common Name	me Specify the client's common name.			
Client IP address Specifies the client's virtual IP address.		Null		

This section allows you to view the status of the OpenVPN tunnel.

OpenVI	PN	Status	x509			
∧ OpenVPN Tunnel Status						
Index	Description	Status	Uptime	Local IP		


User can upload the X509 certificates for the OpenVPN in this section.

OpenVPN	Status x5	09	
∧ X509 Settings			7
	Tunnel Name	Tunnel 1 v	
	Root CA	Choose File No file chosen	
	Certificate File	Choose File No file chosen	
	Private Key	Choose File No file chosen	
	TLS-Auth Key	Choose File No file chosen	
	PKCS#12 Certificate	Choose File No file chosen	
	Pre-Share Key	Choose File No file chosen	

Certificate Files

Index File Name File Size Modification Time

x509				
ltem	Description			
	X509 Settings			
Tunnel Name	Choose a valid tunnel.	Tunnel 1		
Mode	Set for the selected tunnel.	Client		
Root CA	Click on "Choose File" to locate the root ca file, and then import this file into	Null		
	your router.			
Certificate File	Click on "Choose File" to locate the certificate file, and then import this file			
	into your router.			
Private Key	Click on "Choose File" to locate the private key file, and then import this file			
	into your router.			
TLS-Auth Key	Click on "Choose File" to locate the tls-auth key file, and then import this file			
	into your router.			
PKCS#12 Certificate	Click on "Choose File" to locate the pkcs#12 certificate file, and then import			
	this file into your router.			
	Certificate Files			
Index	Indicate the ordinal of the list.			
File Name	Show the imported certificate's name.	Null		
File Size	Show the size of the certificate file.	Null		
Modification Time	Show the timestamp of that the last time to modify the certificate file.	Null		

4.4.3 GRE

This section allows you to set the GRE and the related parameters. GRE (Generic Routing Encapsulation) specifies how one network protocol can be used to encapsulate another. There are two main uses of the GRE protocol: intra-enterprise protocol encapsulation and private address encapsulation.





Click + to add tunnel settings. The maximum count is 5.

GRE	
▲ Tunnel Settings	
Index	1
Enable	ON OFF
Description	
Remote IP Address	
Local Virtual IP Address	
Local Virtual Netmask	
Remote Virtual IP Address	
Enable Default Route	ON OFF
Enable NAT	ON OFF
Secrets	

Tunnel Settings @ GRE			
Item	Item Description		
Index	Indicate the ordinal of the list.		
Enable	Click the toggle button to enable/disable this GRE tunnel.	ON	
Description	Enter a description for this GRE tunnel.	Null	
Remote IP Address	Set the remote real IP address of the GRE tunnel.	Null	
Local Virtual IP Address	Set the local virtual IP address of the GRE tunnel.	Null	
Local Virtual Netmask	Set the local virtual Netmask of the GRE tunnel.	Null	
Remote Virtual IP Address	Set the remote virtual IP Address of the GRE tunnel.	Null	
Enable Default Route	Click the toggle button to enable/disable this option. When enabled, all	OFF	
	the traffics of the router will go through the GRE VPN.		
Enable NAT	Click the toggle button to enable/disable this option. This option must be	Disable	
	enabled when router under NAT environment.		
Secrets	Set the key of the GRE tunnel.	Null	

This section allows you to view the status of GRE tunnel.

GRE		Status		
∧ GRE tu	nnel status			
Index	Description	Status	Local IP Address Remote IP Address	Uptime



4.5 Services

4.5.1 Syslog

This section allows you to set the syslog parameters. And its "Log to Remote" is disabled by default. The system log can be saved locally, and sending the system log to the remote log server is supported, as well as the debugging of specified applications.

Syslog		
∧ Syslog Settir	igs	
	Enable	ON OFF
	Syslog Level	Debug v
	Save Position	RAM V 🖓
	Log to Remote	ON OFF ?

The window is displayed as below when enabling the "Log to Remote" option.

Syslog		
Syslog Setting	gs	
	Enable	ON OFF
	Syslog Level	Debug v
	Save Position	RAM V 🖓
	Log to Remote	
	Add Identifier	ON OFF ?
	Remote IP Address	
	Remote Port	514

Syslog Settings				
Item	Description	Default		
Enable	Click the toggle button to enable/disable the Syslog settings option.	OFF		
Syslog Level	Select from "Debug", "Info", "Notice", "Warning" or "Error", which from low to	Debug		
	high. The lower level will output more syslog in detail.			
Save Position	Select the save position from "RAM", "NVM" or "Console". Choose "RAM", the	RAM		
	data will be cleared after reboot. Note : It's not recommended that saving syslog to NVM (Non-Volatile Memory)			
	for a long time.			
Log to Remote	Click the toggle button to enable/disable this option. Enable to allow router	OFF		
	sending syslog to the remote syslog server. You need to enter the IP and Port of			
	the syslog server.			
Add Identifier	Click the toggle button to enable/disable this option. When enabled, you can add	OFF		
	serial number to syslog message which used for loading Syslog to RobustLink.			



+

Remote IP Address	Enter the IP address of syslog server when enabling the "Log to Remote" option.	Null
Remote Port	Enter the port of syslog server when enabling the "Log to Remote" option.	514

4.5.2 Event

This section allows you to set the router events. It can be configured to send event alerts via SMS or report router event occurrences via SNMP-TRAP and RCMS.

Event	Notification	Query	
∧ General Setti	ngs		
	Signal Quality	Threshold 0	0

General Settings @ Event			
Item	Description		
Signal Quality ThresholdSet the threshold for signal quality. Router will generate a log event when the actual threshold is less than the specified threshold. 0 means disable this option.		0	
Event Notific	ation Query		

• Event Notification Group Settings					
Index	Description	Send SMS	Send Email	Save to NVM	

Click + button to add event parameters.

∧ General Settings	
Index	1
Description	
Send SMS	ON OFF
Send Email	ON OFF
DO Control	ON OFF
Save to NVM	ON OFF ?

• Event Selection	
System Startup	OM OFF
System Reboot	ON OFF
System Time Update	ON OFF
Configuration Change	OFF
Cellular Network Type Change	ON OFF
Cellular Data Stats Clear	OFF OFF
Cellular Data Traffic Overflow	OFF
Poor Signal Quality	OFF
Link Switching	OH OFF
WAN Up	ON OFF
WAN Down	ON OFF
WLAN Up	OFF
WLAN Down	OFF
WWAN Up	OFF
WWAN Down	ON OFF
IPSec Connection Up	OFF
IPSec Connection Down	OH OFF
OpenVPN Connection Up	ON OFF
OpenVPN Connection Down	ON OFF
LAN Port Link Up	OT OFF
LAN Port Link Down	ON OFF
USB Device Connect	OFF OFF
USB Device Remove	ON OFF
DDNS Update Success	OH OFF
DDNS Update Fail	OH OFF
Received SMS	ON OFF
SMS Command Execute	OFF
DI 1 ON	OFF
DI 1 OFF	OFF
DI 1 Counter Overflow	OH OFF

General Settings @ Notification		
Item	Description	Default
Index	Indicate the ordinal of the list.	





Description	Enter a description for this group.	Null
Sent SMS	Click the toggle button to enable/disable this option. When enabled, the router will	OFF
	send notification to the specified phone numbers via SMS if event occurs. The	
	specified phone number is set in "4.5.4 SMS".	
Phone Number	Enter the phone numbers used for receiving event notification. Use a semicolon (;)	Null
	to separate each number.	
Send Email	Click the toggle button to enable/disable this option. When enabled, the router will	OFF
	send notification to the specified email box via Email if event occurs. Set the related	
	email address in "4.5.5 Services > Email".	
Email Addresses	Enter the email addresses used for receiving event notification. Use a space to	Null
	separate each address.	
DO Control	Click the toggle button to enable/disable this option. When enabled, the DO output	OFF
	is triggered.	
Save to NVM	Click the toggle button to enable/disable this option. Enable to save event to	OFF
	nonvolatile memory.	

In the "Query" column, you can query the occurrence records of various events. Select the storage location, enter keywords in the filter item to filter events, and use the separator "&" to separate two or more keywords. Click **Refresh** to query filtered events while click **Clear** to clear the event records in the window.

Event	Notification	Que	ry		
∧ Event Detail	s				
		Save Position	RAM		
		Filtering			
Apr 18 15:57:05, Apr 18 15:57:58, Apr 18 16:04:59, Apr 18 16:05:37, Apr 18 16:05:37, Apr 18 16:05:46, Apr 18 16:05:52, Apr 18 16:06:05, Apr 18 16:06:05, Apr 18 16:06:06:40, Apr 18 16:06:28, Apr 18 16:06:40, Apr 18 16:06:44, Apr 18 16:06:44, Apr 18 16:07:16, Apr 18 16:07:16, Apr 18 16:07:16, Apr 18 16:07:51, Apr 18 16:09:12, Apr 18 16:09:20, Apr 18 16:11:14, Apr 18 16:11:24, Apr 18 16:11:24, Apr 18 16:11:34,	configuration change, configuration change, configuration change, configuration change, configuration change, configuration change, configuration change, configuration change, USB device remove USB device remove configuration change, configuration change, uSB device connect USB device connect USB device remove configuration change, configuration change, configuration change, configuration change, configuration change, configuration change, configuration change, configuration change, configuration change, USB device connect USB device remove configuration change, USB device remove configuration change, configuration change,	via web manager via web manager			
L				Clear	Refresh

Event Details		
Item	Description	Default
Save Position	Select the events' save position from "RAM" or "NVM".	RAM



	 RAM: Random-access memory NVM: Non-Volatile Memory 	
Filter Message	Event will be filtered according to the Filter Message that the user set. Click the	Null
	"Refresh" button, the filtered event will be displayed in the follow box. Use "&" to	
	separate more than one filter message, such as message1&message2.	

4.5.3 NTP

This section allows you to set the related NTP (Network Time Protocol) parameters.

NTP	Status	
∧ Timezone Set	tings	
	Time Zone	UTC+08:00 V
	Expert Setting	
∧ NTP Client Set	ttings	
	Enable	ON OFF
	Primary NTP Server	pool.ntp.org
	Secondary NTP Server	
	NTP Update Interval	0 7
∧ NTP Server Se	ettings	
	Enable	OM OFF

NTP			
Item	Description	Default	
	Timezone Settings		
Time Zone	Click the drop down list to select the time zone you are in.	UTC +08:00	
Expert Setting	Specify the time zone with Daylight Saving Time in TZ environment	Null	
	variable format. The Time Zone option will be ignored in this case. Not		
	support setting special characters, such as" ~ ".		
NTP Client Settings			
Enable	Click the toggle button to enable/disable this option. Enable to	ON	
	synchronize time with the NTP server.		
Primary NTP Server	Enter primary NTP Server's IP address or domain name.	pool.ntp.org	
Secondary NTP Server	Enter secondary NTP Server's IP address or domain name.	Null	
NTP Update interval	Enter the interval (minutes) which NTP client synchronize the time from	0	
	NTP server. Minutes wait for next update, and 0 means update only		
	once.		
NTP Server Settings			
Enable	Click the toggle button to enable the NTP server option.	OFF	



This window allows you to view the current time of router and also synchronize the router time. Click Sync button to synchronize the router time with PC's.

∧ Time	
System Time	2021-01-04 16:03:46
PC Time	2021-01-04 16:03:46 Sync
Last Update Time	2021-01-04 11:53:57

4.5.4 SMS

This section allows you to set SMS parameters. Router supports SMS management, and user can control and configure their routers by sending SMS. For more details about SMS control, refer to **5.1.2 SMS Remote Control**.

SMS	SMS Testing			
∧ SMS Managen	∧ SMS Management Settings			
	Enable	ON OFF		
	Authentication Type	Password v		
	Phone Number			

SMS Management Settings			
Item	Description		
Enable	Click the toggle button to enable/disable the SMS Management option.	ON	
	Note: If this option is disabled, the SMS configuration is invalid.		
Authentication Type	Select Authentication Type from "Password", "Phonenum" or "Both".	Password	
	 Password: Use the same username and password as WEB manager for 		
	authentication. For example, the format of the SMS should be "username: password; cmd1; cmd2;"		
	Note: Set the WEB manager password in System > User Management section.		
	• Phonenum: Use the Phone number for authenticating, and user should set		
	the Phone Number that is allowed for SMS management. The format of		
	the SMS should be "cmd1; cmd2;"		
	• Both: Use both the "Password" and "Phonenum" for authentication. User		
	should set the Phone Number that is allowed for SMS management. The		
	format of the SMS should be "username: password; cmd1; cmd2;"		
Phone Number	Set the phone number used for SMS management, and use '; 'to separate each	Null	
	number.		
	Note: It can be null when choose "Password" as the authentication type.		



User can test the current SMS service whether it is available in this section.

SMS	SMS Testing	
∧ SMS Testing		
Phone Number		
Message		
Result		
		Send

	SMS Testing	
Item	Description	Default
Phone Number	Enter the specified phone number which can receive the SMS from router.	Null
Message	Enter the message that router will send it to the specified phone number.	Null
Result	The result of the SMS test will be displayed in the result box. For example, if the	
	SMS is sent successfully, this result box will show "OK".	
Send	Click the button to send the test message.	

4.5.5 Email

Email function supports to send the event notifications to the specified recipient by ways of email.

Email		
∧ Email Setting	S	
	Enable	ON OFF
	Enable TLS/SSL	ON OFF ?
	Enable STARTTLS	ON OFF
	Outgoing Server	
	Server Port	25
	Timeout	10 🦻
	Auth Login	ON OFF ?
	Username	
	Password	
	From	
	Subject	



	Email Settings	
Item	Description	Default
Enable	Click the toggle button to enable/disable the Email option.	OFF
Enable TLS/SSL	Click the toggle button to enable/disable the TLS/SSL option.	OFF
Enable STARTTLS	Click the toggle button to enable/disable the STARTTLS option.	OFF
Outgoing server	Enter the SMTP server IP Address or domain name.	Null
Server port	Enter the SMTP server port.	25
Timeout	Set the max time for sending email to SMTP server. When the server doesn't	10
	receive the email over this time, it will try to resend.	
Auth Login	Use username and password to authenticate.	OFF
Username	Enter the username which has been registered from SMTP server.	Null
Password	Enter the password of the username above.	Null
From	Enter the source address of the email.	Null
Subject	Enter the subject of this email.	Null

4.5.6 DDNS

DDNS, full name Dynamic Domain Name Server, allows a dynamic IP address to be mapped to a fixed domain name resolution service, each time a user connects to the network the client program will transmit the dynamic IP address of the host to the server program located on the service provider's host through messaging. The server program is responsible for providing DNS services and implementing dynamic domain name resolution, i.e. DDNS service allows you to assign a fixed domain name to the host's dynamic WAN IP, and other users can access your host directly through this fixed domain name, instead of through the dynamic WAN IP address. The router's dynamic WAN IP address is assigned directly by the ISP.

DDNS	Status		
DDNS Setting	S		
		Enable	ON OFF
		Service Provider	DynDNS
		Hostname	
		Username	
		Password	

Click "Services > DDNS" to set the parameters for DDNS, the default service provider is "DynDNS".

When "Custom" service provider chosen, the window is displayed as below.

∧ DDNS Settings		
	Enable	ON OFF
	Service Provider	Custom
	URL	



	DDNS Settings	
Item	Description	Default
Enable	Click the toggle button to enable/disable the DDNS option.	OFF
Service Provider	Select the DDNS service from "DynDNS", "NO-IP", "3322" or "Custom". Note: the DDNS service only can be used after registered by Corresponding service provider.	DynDNS
Hostname	Enter the hostname provided by the DDNS server.	Null
Username	Enter the username provided by the DDNS server.	Null
Password	Enter the password provided by the DDNS server.	Null
URL	Enter the URL customized by user.	Null

DDNS	Status	
∧ DDNS Status		
		Status Disabled
	Last Upda	ate Time

	DDNS Status
Item	Description
Status	Display the current status of the DDNS.
Last Update Time	Display the date and time for the DDNS was last updated successfully.

4.5.7 SSH

Router supports SSH password access and secret-key access.

SSH	Keys Management	
∧ SSH Settings		
	Enable	ON OF
	Port	22
	Disable Password Logins	OMOFF

	SSH Settings	
Item	Description	Default
Enable	Click the toggle button to enable/disable this option. When enabled, you can	ON
	access the router via SSH.	
Port	Set the port of the SSH access.	22
Disable Password Logins	Click the toggle button to enable/disable this option. When enabled, you	OFF



SSH	Keys Management		
∧ Import Authorized Keys			
	Authorized Keys	Choose File No file chosen	Import

Import Authorized Keys		
Item	Description	
Authorized Keys	This is valid when disabling password login is enabled. Importing a correct public key	
	from your computer to the router will allow users to SSH directly to the router	
	without a password.	

4.5.8 Ignition

This section is used to configure the parameters of Ignition. Ignition is an application for the in-car ignition sensing. Ignition and POE function can only choose one or the other.

Ignition	
∧ General Settings	
Enable	ON OFF
Delay shutdowr	60 ?

General Settings		
Item	Description	Default
Waiting time	Enter the time in seconds you want to delay power down. The timeout for delayed power down is 60 seconds to 3600 seconds.	60

4.5.9 GPS

This section is used to configure the parameters of GPS. The GPS function can locate and obtain the location information and report it to the designated server. The R5020 does not have a separate GPS module and the location data comes from the cellular module.

10 robustel



G	PS	Status	Ma	ар			
∧ Gene	eral Setti	ngs					
			Enable GPS	ON OFF			
			Sync GPS Time	ON OFF			
^ RS23	32 Report	Settings					
			Report to RS232	ON OFF			
		Rep	ort GGA Sentence	ON OFF			
		Rep	oort VTG Sentence	ON OFF			
		Rep	ort RMC Sentence	ON OFF			
		Rep	oort GSV Sentence	ON OFF			
^ GPS	Servers						
Index	Enable	Protocol	Local Address	Local Port	Server Address	Server Port	+
^ Adva	nced Set	tings					
			Add SN as GPSID	ON OFF	?		
		Self-de	efine GPSID Prefix				

GPS				
Item	Description	Default		
	General Settings			
Enable	Click the toggle button to ON to enable GPS.	OFF		
Synchronized GPS Time	Click the toggle button to ON to synchronize GPS time.	OFF		
	RS232 Report Data Settings			
Reporting data through RS232	Reporting GPS Information by RS232.	OFF		
Reporting GGA Information	Reporting GGA Information.	OFF		
Reporting VTG Information	Reporting VTG Information.	OFF		
Reporting RMC Information	Reporting RMC Information.	OFF		
Reporting GSV Information	Reporting GSV Information.	OFF		



Click the Add button in the GPS server window, and the protocol defaults to "TCP Client" as follows:

GPS	
∧ Server Settings	
Index	1
Enable	ON OFF
Protocol	TCP Client v
Server Address	
Server Port	
Send GGA Sentence	ON OFF
Send VTG Sentence	ON OFF
Send RMC Sentence	ON OFF
Send GSV Sentence	ON OFF
	Submit Close

When selecting "TCP Server" as the protocol, the window appears as follows:

GPS	
∧ Server Settings	
Index	1
Enable	ON OFF
Protocol	TCP Server
Local Address	
Local Port	
Send GGA Sentence	ON OFF
Send VTG Sentence	ON OFF
Send RMC Sentence	ON OFF
Send GSV Sentence	ON OFF
	Submit Close



When selecting "UDP" as the protocol, the window appears as follows:

∧ Server Settings	
Index	1
Enable	ON OFF
Protocol	UDP
Server Address	
Server Port	
Send GGA Sentence	ON OFF
Send VTG Sentence	ON OFF
Send RMC Sentence	ON OFF
Send GSV Sentence	ON OFF

GPS Data Forwarding Settings		
Item	Description	Default
Index	Indicate the ordinal of the list.	
Enable	Click the toggle button to "ON" to enable the GPS data forwarding settings.	ON
Protocol	 Select "TCP client", "TCP server" or "UDP" as the protocol. TCP Client: When the router acts as a TCP client, it starts up with the TCP server (GPS server). The address of the server supports both IP and domain name. TCP server: The router acts as a TCP server (GPS server) and listens for connection requests from TCP clients. UDP: Router as a UDP client. 	TCP Client
Server address @TCP client	Set the address of the TCP server.	Null
Server port @TCP client	Set the port of the remote TCP server	Null
Local address	Set the local address of the router as a TCP server.	Null
Local port	Set the local port of the router as a TCP server.	Null
Server address @UDP	Set the address of the TCP server	Null
Server port @UDP	Set the port of the remote TCP server.	Null
Send GGA information	Send GGA information in NMEA format	OFF
Send VTG information	Send VTG information in NMEA format	OFF
Send RMC information	Send RMC information in NMEA format	OFF



GPS Data Forwarding Settings		
Item	Description	Default
Send GSV	Send GSV information in NMEA format	OFF
information		UFF

∧ Advanced Settings	
Add SN as GPSID	ON OFF 😨
Self-define GPSID Prefix	

Advanced Settings		
Item	Description	Default
Add SN as GPSID	Click the toggle button to enable/disable this option. When enabled, the SN is appended to the NMEA message as a GPSID before transmission.	OFF
Self-define GPSID Prefix	Customize the GPSID prefix with a 4-capital letter prefix.	Null

Click the Status bar to view the current GPS status;

GPS	Status	Ма	ap
∧ GPS Status			
		Status	Not Fixed
		UTC Time	2017-09-15 07:18:23
	Last	Fixed Time	2017-09-14 12:36:58 UTC
	Satell	ites In Use	4
	Satellit	es In View	12
		Latitude	23.1534988
		Longitude	113.4013826
		Altitude	29.0 m
		Speed	1.947 m/s

GPS Status			
Item	Description		
Status	Shows the current GPS status of the router.		
	Shows the UTC of satellite.		
UTC	Note: UTC is the world's unified time, not local time.		
Final positioning	The time of the last successful peritiening		
time	The time of the last successful positioning.		
Number of	Number of satellites used		
satellites used			



GPS Status			
Item	Description		
Number of visible satellites	Number of visible satellites		
Latitude	Shows the Latitude information of the router.		
Longitude	Shows the longitude information of the router.		
Height	Shows the height information of the router.		
Speed	Shows the speed information of the router.		

Click the Map bar to view the current geolocation.



4.5.10Web Server

This section allows you to modify the parameters of Web Server.



Web Server	Certificate Management		
∧ General Settir	ıgs		
	HTTP Port	80	?
	HTTPS Port	443	7

General Settings @ Web Server			
Item	Description	Default	
HTTP Port	Enter the HTTP port number you want to change in router's Web Server. On a	80	
	Web server, port 80 is the port that the server "listens to" or expects to receive		
	from a Web client. If you configure the router with other HTTP Port number		
	except 80, only adding that port number then you can login router's Web		
	Server.		
HTTPS Port	Enter the HTTPS port number you want to change in router's Web Server. On a	443	
	Web server, port 443 is the port that the server "listens to" or expects to		
	receive from a Web client. If you configure the router with other HTTPS Port		
	number except 443, only adding that port number then you can login router's		
	Web Server.		
	Note: HTTPS is more secure than HTTP. In many cases, clients may be		
	exchanging confidential information with a server, which needs to be secured in		
	order to prevent unauthorized access. For this reason, HTTP was developed by		
	Netscape corporation to allow authorization and secured transactions.		

This section allows you to import the certificate file into the router.

Web Server	Certificate Management		
∧ Import Certi	ficate		
	Import Type	CA	
	HTTPS Certificate	Choose File No file chosen	Import

Import Certificate			
Item	Description	Default	
Import Type	Select from "CA" and "Private Key".	CA	
	CA: a digital certificate issued by CA center		
	Private Key: a private key file		
HTTPS Certificate	Click on "Choose File" to locate the certificate file from your computer, and then		
	click "Import" to import this file into your router.		

4.5.11 Advanced

Router advanced settings including system settings and reboot.



System	Reboot	
∧ System Setting	js	
	Device Na	ne router
	User LED Ty	pe None v

System Settings				
Item	Description	Default		
Device Name	Set the device name to distinguish different devices you have installed; valid	router		
	characters are a-z, A-Z, 0-9, @, ., -, #, \$, and *.			
User LED Type	Specify the display type of your USR LED. Select from "None", "OpenVPN" or	None		
	"IPsec".			
	None: Meaningless indication, and the LED is off			
	• SIM:show the sim status.			
	OpenVPN: USR indicator showing the OpenVPN status			
	IPsec: USR indicator showing the IPsec status			
	Note: For more details about USR indicator, see "2.2 LED Indicators".			

System	Reboot	
∧ Periodic Reboo	t Settings	
	Periodic Reboot	0 7
	Daily Reboot Time	

Reboot			
Item	Description	Default	
Periodic Reboot	Set the reboot period of the router. 0 means disable.	0	
Daily Reboot Time	Set the daily reboot time of the router, you should follow the format as HH: MM, in 24h time frame, otherwise the data will be invalid. Leave it empty means disable.	Null	

4.6 System

4.6.1 Debug

This section is used to view and generate the system operation logs and diagnostic data. Click **Service > System Log > System Log Settings** to open the system log.



Syslog					
∧ Syslog Detai	ls				
	ı	Log Level	Debug	v	
		Filtering		0	
Feb 27 14:29:07 r Feb 27 14:29:23 r "D064810301250082 A03804FBF6C11670D Feb 27 14:31:23 r "D064810301250082 A03804FBF6C11670D Feb 27 14:33:23 r "D064810301250082 A03804FBF6C11670D Feb 27 14:34:07 r Feb 27 14:36:23 r "D064810301250082	FilteringImage: [842]: target link WWANI, state ConnectedFeb 27 14:29:07 router user.info link manage: [842]: target link WWANI, state ConnectedFeb 27 14:29:23 router user.debug modemd[876]: +CUSATP:"D064810301250082028182560F80005500530049004D53615E9475288F0A01807CEE54C163A883508F0A02806C83901A884C8BC18F0A03804FEF6C11670D52A18F0C0480624B673A84254E1A53858F0A0580F04191CF4E13533A8F0A0680727960E0793C5305"Feb 27 14:31:23 router user.debug modemd[876]: +CUSATP:"D064810301250082028182850F80005500530049004D53615E9475288F0A01807CEE54C163A883508F0A02806C83901A884C8BC18F0A03804FEF6C11670D52A18F0C0480624B673A84254E1A53858F0A0580F0A191CF4E13533A8F0A0680727960E0793C5305"Feb 27 14:33:23 router user.debug modemd[876]: +CUSATP:"D064810301250082028182850F80005500530049004D5361EE9475288F0A01807CEE54C163A883508F0A02806C33901A884C8BC18F0A03804FEF6C11670D52A18F0C0480624B673A84254E1A53858F0A0580F0A191CF4E13533A8F0A0680727960E0793C5305"Feb 27 14:34:07 router user.debug rping[16182]: start ping 8.8.8.8 (wwan)Feb 27 14:34:07 router user.debug rping[16182]: e12 WWANI (wwan) start ping testFeb 27 14:34:07 router user.debug rping[16182]: e24 bytes from 8.8.8.8 (seq=0 tt1=52 time=324.080 msFeb 27 14:34:07 router user.debug rping[16182]: cound-trip min/avg/max = 324.080/324.080/324.080 msFeb 27 14:34:07 router user.debug rping[16182]: round-trip min/avg/max = 324.080/324.080/324.080 msFeb 27 14:34:07 router user.debug rping[16182]: round-trip min/avg/max = 324.080/324.080 msFeb 27 14:34:07 router user.debug rping[16182]: round-trip min/avg/max = 324.080/324.080 msFeb 27 14:34:07 router user.debug rping[16182]: round-trip min/avg/max = 324.080/324.080 msFeb 27 14:34:07 router user.				
			Manual Refresh	v Clear	Refresh
Syslog Files					
Index F	ile Name	File Size	e Mod	lification Time	
1	messages	112612	Mon Feb	27 14:35:23 2017	
∧ System Diag	nostic Data				
	System Diagnos	stic Data	Generate		
	System Diagnos	stic Data	Download		

Syslog					
Item	Description				
	Syslog Details				
Log Level	Select from "Debug", "Info", "Notice", "Warn", "Error" which from low to high. The lower				
	level will output more syslog in detail.				
Filtering	Enter the filtering message based on the keywords. Use "&" to separate more than one filter				
	message, such as "keyword1&keyword2".				
Refresh	Select from "Manual Refresh", "5 Seconds", "10 Seconds", "20 Seconds" or "30 Seconds". You				
	can select these intervals to refresh the log information displayed in the follow box. If				
	selecting "manual refresh", you should click the refresh button to refresh the syslog.				
Clear	Click the button to clear the syslog.				
Refresh	Click the button to refresh the syslog.				
	Syslog Files				
Syslog Files	Only when logging is enabled in "Service > System Log > Enable" files will be displayed in this				
	list. The logs are generated in one file of 200k size, and up to 6 system log files can be				
	displayed. 5 files with the file name of messages0~messages4 are old logs, and the latest				



	system log file messages will be on top.			
System Diagnosing Data				
Generate	Click to generate the syslog diagnosing file.			
Download	Click to download system diagnosing file.			

4.6.2 Update

This section is used to upgrade the router system to import and update the firmware file to implement the system update. Import a firmware file from your computer to your router and click **Update** to start the upgrade process. And follow the system prompts to reboot the device to complete the firmware update.

Note: To access the latest firmware file, please contact your technical support engineer.

Update				
∧ System Update				
	File	Chance File	No file chosen	Update

4.6.3 App Center

The router supports App import. You can import and install the app directly in this application, and reboot the device according to the system prompt. After successful installation, the app will be displayed in the "Services" column, while other VPN apps will be displayed in the "VPN" column after installation.

Note: After importing the applications to the router, the page display may have a slight delay due to the browser cache. It is recommended that you clear the browser cache first and log in the router again.

App Center			
For more inform	ation about APP Center, refer t	o http://www.robustel.com/produc	ts/app-center/
App Install			
	File	Choose File No file chosen	Install

The successfully installed app will be shown in the following list, click \times to uninstall the app.

∧ Installed Apps					
Index	Name	Version	Status	Description	
1	vrrp	3.0.0	Stopped	VRRP Daemon	×
2	language_chinese	3.0.0	Stopped	Chinese language	×

App Center					
Item	Description	Default			
	App Install				
File	Click on "Choose File" to locate the App file from your computer, and then click				
	Install to import this file into your router.				
	Note: File format should be xxx.rpk, e.g. R5020-robustlink-1.0.0.rpk.				



App Center					
Item Description					
	App Install				
Installed Apps					
Index	Indicate the ordinal of the list.				
Name	Show the name of the App.	Null			
Version	Show the version of the App.	Null			
Status	Show the status of the App.	Null			
Description	Show the description for this App.	Null			

4.6.4 Tools

This section provides users three tools: Ping, Traceroute and Sniffer. The Ping tool is used to detect the network connectivity of the router.

Ping	Traceroute	Snift	fer
∧ Ping			
	1	P Address	
	Number o	of Request	5
		Timeout	1
		Local IP	
			Start Stop

Ping				
Item	Description	Default		
IP address	Enter the ping's destination IP address or destination domain.	Null		
Number of Requests	Specify the number of ping requests.	5		
Timeout	Specify the timeout of ping request.	1		
Local IP	Specify the local IP from cellular WAN, Ethernet WAN or Ethernet LAN. Null	Null		
	stands for selecting local IP address from these three automatically.			



Start	Click this button to start ping request, and the log will be displayed in the follow box.	
Stop	Click this button to stop ping request.	

Ping	Traceroute Snif	fer
∧ Traceroute		
	Trace Address	
	Trace Hops	30
	Trace Timeout	1
		Start Stop

Traceroute				
Item	Description	Default		
Trace Address	Enter the trace's destination IP address or destination domain.	Null		
Trace Hops	Specify the max trace hops. Router will stop tracing if the trace hops has met	30		
	max value no matter the destination has been reached or not.			
Trace Timeout	Specify the timeout of Traceroute request.	1		
Start	Click this button to start Traceroute request, and the log will be displayed in			
	the follow box.			
Stop	Click this button to stop Traceroute request.			



Pin	ng Traceroute	Snif	fer			
∧ Sniffe	er					
		Interface	all	v		
		Host				
	Pa	ckets Request	1000			
		Protocol	All	v		
		Status	0			
					Start	Stop
∧ Captı	ıre Files					
Index	File Name	File Siz	e	Modification Tin	е	
1	18-04-18_16-17-29.cap	24		Wed Apr 18 16:17:30	2018	

Sniffer				
Item	Description	Default		
Interface	Choose the interface according to your Ethernet configuration. All			
Host	Filter the packet that contain the specify IP address.	Null		
Packets Request	Set the packet number that the router can sniffer at a time.	1000		
Protocol Select from "All", "IP", "TCP", "UDP" and "ARP". All		All		
Status Show the current status of sniffer.				
Start Click this button to start the sniffer.				
Stop	Click this button to stop the sniffer. Once you click this button, a new log file			
stop	will be displayed in the following List.			
Capture Files	Every times of sniffer log will be saved automatically as a new file. You can find			
the file from this Sniffer Traffic Data List and click 💽 to download the log, click				
Xto delete the log file. It can cache a maximum of 5 files.				

4.6.5 Profile

This section allows you to import or export the configuration file, and restore the router to factory default setting.



Profile	Rollback	
∧ Import Confi	guration File	
	Reset Other Settings to Default	ON OFF ?
	Ignore Invalid Settings	ON OFF ?
	XML Configuration File	Choose File No file chosen Import
A Export Config	juration File	
	Ignore Disabled Features	ON OFF ?
	Add Detailed Information	ON OFF 7
	Encrypt Secret Data	ON OFF ?
	XML Configuration File	Generate
∧ Default Confi	guration	
Save I	Running Configuration as Default	Save
	Restore to Default Configuration	Restore

Profile				
Item	Description	Default		
	Import Configuration File			
Reset Other Settings to	Click the toggle button as "ON" to return other parameters to default	OFF		
Default	settings.			
Ignore Invalid Settings	Click the toggle button as "ON" to ignore invalid settings.	OFF		
XML Configuration File	Click on Choose File to locate the XML configuration file from your			
	computer, and then click Import to import this file into your router.			
Export Configuration File				
Ignore Disabled Features	Click the toggle button as "ON" to ignore the disabled features.	OFF		
Add Detailed Information	Click the toggle button as "ON" to add detailed information.	OFF		
Encrypt Secret Data	Click the toggle button as "ON" to encrypt the secret data.	ON		
XML Configuration File	Click Generate button to generate the XML configuration file, and click			
	Export to export the XML configuration file.			
	Default Configuration			
Save Running	Click Save button to save the current running parameters as default			
Configuration as Default configuration.				
Restore to DefaultClick "restore" button to restore the factory defaults.				
Configuration				

Profile	Rollbac	k				
∧ Configura	∧ Configuration Rollback					
	Save as a Ro	Ilbackable Archive Save	0			
Configuration Archive Files						
Index	File Name	File Size	Modification Time			



Rollback					
Item Description De					
	Configuration Rollback				
Save as a Rollbackable	Create a save point manually. Additionally, the system will create a save				
Archive point every day automatically if configuration changes.					
	Configuration Archive Files				
Configuration Archive View the related information about configuration archive files, including					
Files	name, size and modification time.				

4.6.6 User Management

This section allows you to change your username and password, and create or manage user accounts. One router has only one super user who has the highest authority to modify, add and manage other common users.

Super User	Common User				
∧ Super User Se	∧ Super User Settings				
	New Username	0			
	Old Password	0			
	New Password	0			
	Confirm Password				

Super User Settings				
Item	Description	Default		
New Username	v Username Enter a new username you want to create, If you do not want to change Nu			
	username, leave it blank. 5-32 characters, valid characters: a-z, A-Z, 0-9, @, #,			
	\$, ., *, !, -			
Old Password	Enter the old password of your router. The default is "admin",5-32 characters, Null			
	valid characters: a-z, A-Z, 0-9, @, #, \$, ., *, !, -			
New Password Enter a new password you want to create, 5-32 characters, valid characters: N		Null		
	a-z, A-Z, 0-9, @, #, \$, ., *, !, -			
Confirm PasswordEnter the new password again to confirm.Null				

Super User		Common User	
∧ Common l	Jser S	Settings	
Index	Role	Username	+



Click + button to add a new common user. The maximum rule count is 5.

Common User	
∧ Common Users Settings	
Index	1
Role	Visitor
Username	
Password	

Common User Settings					
Item	Description Default				
Index	Indicate the ordinal of the list.	ndicate the ordinal of the list			
Role	Select from "Visitor" and "Editor". Visitor				
	• Visitor: Users only can view the configuration of router under this level				
	Editor: Users can view and set the configuration of router under this level				
Username	Set the Username, 5-32 characters, valid characters: a-z, A-Z, 0-9, @, #, \$, ., *, !, - Null				
Password	Set the password, 5-32 characters, valid characters: a-z, A-Z, 0-9, @, #, \$, ., *, !, - Null				



Chapter 5 Configuration Examples

5.1 Cellular

5.1.1 Cellular Dial-Up

This section shows you how to configure the primary and backup SIM card for Cellular Dial-up. Connect the router correctly and insert two SIM, then open the configuration page. Under the homepage menu, click **Interface > Link Manager > Link Manager > General Settings**, choose "WWAN1" as the primary link and "WWAN2" as the backup link, and set "Cold Backup" as the backup mode, then click "Submit".

Note: All data will be transferred via WWAN1 when choose WWAN1 as the primary link and set backup mode as cold backup. At the same time, WWAN2 is always offline as a backup link. All data transmission will be switched to WWAN2 when the WWAN1 is disconnected.

Link Mar	nager	Status		
∧ Gener	al Setting	s		
			Primary Link	WWAN1 7
			Backup Link	WWAN2 V
			Backup Mode	Cold Backup 🧳 🍞
			Revert Interval	0 3
		Eme	rgency Reboot	ON OFF 7
Link S	ettings			
Index	Туре	Description	Connection Ty	уре
1	WWAN1		DHCP	
2	WWAN2		DHCP	
3	WAN		DHCP	
4	WLAN		DHCP	

Click the edit button of WWAN1 to set its parameters according to the current ISP.

Link Manager	
∧ General Settings	
Index	1
Туре	WWAN1 V
Description	



∧ WWAN Settings	
Automatic APN Selection	ON OFF
Dialup Number	*99***1#
Authentication Type	Auto
Switch SIM By Data Allowance	ON OFF 😨
Data Allowance	0 3
Billing Day	
Ping Detection Settings	0
Enable	ON OFF
Primary Server	8.8.8.8
Secondary Server	114.114.114.114
Interval	300 🧿
Retry Interval	5
Timeout	3
Max Ping Tries	3
∧ Advanced Settings	
NAT Enable	ON OFF
Upload Bandwidth	10000 🕜
Download Bandwidth	10000

Download Bandwidth	10000
Overrided Primary DNS	
Overrided Secondary DNS	
Debug Enable	ON OFF
Verbose Debug Enable	ON OFF

When finished, click **Submit > Save & Apply** for the configuration to take effect.

The window is displayed below by clicking Interface > Cellular > Advanced Cellular Settings.

Cellul	lar	Status	AT Debug		
Advan	ced Cellula	ar Settings			
Index	SIM Card	Phone Number	Network Type	Band Select Type	
1	SIM1		Auto	All	
2	SIM2		Auto	All	



Click the edit button of SIM1 to set its parameters according to your application request.

Cellular	
∧ General Settings	
Index	1
SIM Card	SIM1 V
Phone Number	
PIN Code	
Extra AT Cmd	
Telnet Port	0 7
A Cellular Network Settings	
Network Type	Auto 🤍 🦻
Band Select Type	All ?
 Advanced Settings 	
Debug Enable	ON OFF
Verbose Debug Enable	ON OFF

When finished, click **Submit > Save & Apply** for the configuration to take effect.

5.1.2 SMS Remote Control

The router supports remote control via SMS. You can use following commands to get the status of the router, and set all the parameters. There are three authentication types for SMS control. You can select from "Password", "Phonenum" or "Both".

An SMS command has the following structure:

- 1. Password mode—Username: Password; cmd1; cmd2; cmd3; ...cmdn (available for every phone number).
- 2. Phonenum mode-- **Password; cmd1; cmd2; cmd3; ... cmdn** (available when the SMS was sent from the phone number which had been added in R5020's phone group).
- Both mode-- Username: Password; cmd1; cmd2; cmd3; ...cmdn (available when the SMS was sent from the phone number which had been added in R5020's phone group).
 Note: All command symbols must be entered in the half-angle mode of the English input method.

SMS command Explanation:

- 1. User name and Password: use the same username and password as WEB manager for authentication.
- 2. cmd1, cmd2, cmd3 to Cmdn, the command format is the same as the CLI command, more details about CLI cmd please refer to **Chapter 6 Introductions for CLI**.

Note: Download the configure XML file from the configured web browser. The format of SMS control command can refer to the data of the XML file.

Go to **System > Profile > Export Configuration File**, click **Generate** to generate the XML file and click **Export** to export the XML file.



Profile	Rollback	
∧ Import Config	guration File	
	Reset Other Settings to Default	ON OFF 😨
	Ignore Invalid Settings	ON OFF ?
	XML Configuration File	Choose File No file chosen Import
Export Config	uration File	
	Ignore Disabled Features	ON OFF
	Add Detailed Information	ON OFF ?
	Encrypt Secret Data	ON OFF ?
	XML Configuration File	Generate
∧ Default Confi	guration	
Save F	Running Configuration as Default	Save 🖓
	Restore to Default Configuration	Restore

XML command:

<lan>

<network max_entry_num="2">

<id>1</id>

<interface>lan0</interface>

<ip>172.16.24.24</ip>

<netmask>255.255.0.0</netmask>

<mtu>1500</mtu>

SMS cmd:

set lan network 1 interface lan0 set lan network 1 ip 172.16.24.24 set lan network 1 netmask 255.255.0.0 set lan network 1 mtu 1500

3. The semicolon character (';') is used to separate more than one command packed in a single SMS.

4. E.g.

admin:admin;status system

In this command, username is "admin", password is "admin", and the function of the command is to get the system status.

SMS received:

hardware_version = 1.1 firmware_version = 3.1.0 firmware_version_full = "3.1.0 (Rev 3527)" kernel_version = 4.9.152 device_model = R5020 serial_number = "" uptime = "0 days, 00:02:55" system_time = "Thu May 14 05:51:56 2020 (NTP not updated)"



```
ram usage = "389M Free/448M Total"
admin:admin;reBoot
In this command, username is "admin", password is "admin", and the command is to reBoot the R5020 Router.
SMS received:
OK
admin:admin;set firewall remote_ssh_access false;set firewall remote_telnet_access false
In this command, username is "admin", password is "admin", and the command is to disaBle the
remote_ssh and remote_telnet access.
SMS received:
OK
OK
admin:admin; set lan network 1 interface lan0; set lan network 1 ip 172.16.24.24; set lan network 1 netmask
255.255.0.0;set lan network 1 mtu 1500
In this command, username is "admin", password is "admin", and the commands is to configure
the LAN parameter.
SMS received:
ОК
ОК
OK
OK
```

5.2 VPN Configuration Example

5.2.1 IPsec VPN

IPsec VPN example topology (the IKE and SA parameters must be configured on the server and client):



The configuration of server and client is as follows.

IPsec VPN_Server:



Cisco 2811:

```
Router>enable
Router#config
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line. End with CNTL/Z.
Router(config) #crypto isakmp policy 10
Router(config-isakmp)#?
  authentication Set authentication method for protection suite
  encryption
                  Set encryption algorithm for protection suite
                 Exit from ISAKMP protection suite configuration mode
  exit
  group
                 Set the Diffie-Hellman group
  hash
                  Set hash algorithm for protection suite
                 Set lifetime for ISAKMP security association
  lifetime
                  Negate a command or set its defaults
  no
Router(config-isakmp) #encryption 3des
Router(config-isakmp) #hash md5
Router(config-isakmp) #authentication pre-share
Router(config-isakmp) #group 2
Router(config-isakmp) #exit
Router(config) #crypto isakmp ?
  client Set client configuration policy
  enable Enable ISAKMP
  kev
          Set pre-shared key for remote peer
  policy Set policy for an ISAKMP protection suite
Router(config) #crypto isakmp key cisco address 0.0.0.0 0.0.0.0
Router(config) #crypto ?
  dynamic-map Specify a dynamic crypto map template
              Configure IPSEC policy
  ipsec
              Configure ISAKMP policy
  isakmp
               Long term key operations
  key
  map
               Enter a crypto map
Router(config) #crypto ipsec ?
  security-association Security association parameters
  transform-set
                        Define transform and settings
Router(config)#crvpto ipsec transform-set Trans ?
  ah-md5-hmac AH-HMAC-MD5 transform
  ah-sha-hmac
               AH-HMAC-SHA transform
                ESP transform using 3DES(EDE) cipher (168 bits)
  esp-3des
  esp-aes
               ESP transform using AES cipher
  esp-des
                ESP transform using DES cipher (56 bits)
  esp-md5-hmac ESP transform using HMAC-MD5 auth
  esp-sha-hmac ESP transform using HMAC-SHA auth
Router(config) #crypto ipsec transform-set Trans esp-3des esp-md5-hmac
Router(config) #ip access-list extended vpn
Router(config-ext-nacl) #permit ip 10.0.0 0.0.0.255 192.168.1.0 0.0.0.255
Router(config-ext-nacl) #exit
Router(config) #crypto map cry-map 10 ipsec-isakmp
% NOTE: This new crypto map will remain disabled until a peer
       and a valid access list have been configured.
Router(config-crypto-map) #match address vpn
Router(config-crypto-map) #set transform-set Trans
Router(config-crypto-map) #set peer 202.100.1.1
Router(config-crypto-map) #exit
Router(config) #interface fastEthernet 0/0
Router(config-if) #ip address 58.1.1.1 255.255.255.0
Router(config-if)#cr
Router(config-if) #crypto map cry-map
*Jan 3 07:16:26.785: %CRYPTO-6-ISAKMP_ON_OFF: ISAKMP is ON
```



IPsec VPN Client

The window is displayed as below by clicking **VPN > IPsec > Tunnel**.

Genera	al	Tunnel	Statu	ıs x5	09	
∧ Tunnel	Setting	5				
Index	Enable	Description	Gateway	Local Subnet	Remote Subnet	+

Click + button and set the parameters of IPsec Client as below.

∧ General Settings	
Index	1
Enable	ON OFF
Description	
Gateway	
Mode	Tunnel
Protocol	ESP
Local Subnet	
Remote Subnet	
Link Binding	Unspecified v 🖓
∧ IKE Settings	
Negotiation Mode	Main
Authentication Algorithm	MD5 V
Encryption Algorithm	3DES V
IKE DH Group	DHgroup2
Authentication Type	PSK V
PSK Secret	
Local ID Type	Default v
Remote ID Type	Default



∧ SA Settings	
Encryption Algorithm	3DES v
Authentication Algorithm	SHA1
PFS Group	DHgroup2
SA Lifetime	28800
DPD Interval	30 🧿
DPD Failures	150 🥱
∧ Advanced Settings	
Enable Compression	ON OFF
Enable Forceencaps	ON OFF ?
Expert Options	?

When finished, click **Submit > Save & Apply** for the configuration to take effect.

The comparison between server and client is as below.

Router>enable	Server (Cisco 2811)			
Router≻enable Router≇config				
	terminal, memory, or network [terminal]?	Services 1		
	on commands, one per line. End with CNTL/Z.	Tunnel		
outer(config) #cr	ypto isakmp policy 10	Completion and an and a second second		
outer(config-isa)	kmp)#?	∧ Tunnel Settings		
	Set authentication method for protection suite	Index	1	
encryption	Set encryption algorithm for protection suite			_
exit	Exit from ISAKMP protection suite configuration mode	Enable	ON	
group hash	Set the Diffie-Hellman group Set hash algorithm for protection suite			
lifetime	Set high algorithm for protection suite Set lifetime for ISARMP security association	Description		
no	Negate a command or set its defaults	Gateway	58.1.1.1	0
outer(config-isa)	kmp) #encryption 3des			
outer(config-isa)	kmp)‡hash md5	Mode	Tunnel	
	kmp) #authentication pre-share		ESP	
outer(config-isa)		Protocol	ESP	4
outer (config-isa)	kmp) ‡exit	Local Subnet	192.168.1.0	70
outer(config) #cr;		Local Subject		
	ent configuration policy	Remote Subnet	255.255.255.0	0
enable Enable :				-
	-shared key for remote peer	✓ ∧ IKE Settings		
	vpto isakmp key cisco address 0.0.0.0 0.0.0.0	Newstation Meda	Main	7
ouver (contray) +cr	ypto Isakap key cisco address 0.0.0.0 0.0.0.0	Negotiation Mode	main	4
	IKE Setting in Client must be	consistent with server. Authentication Algorithm	MD5	7
outer(config)#cr				
	acify a dynamic crypto map template	Encrypt Algorithm	3DES N	
	nfigure IPSEC policy			
	nfigure ISAKMP policy	IKE DH Group	MODP(1024)	4
	ng term key operations ter a crypto map	Authentication Type	PSK	
outer(config) #cr				
	ation Security association parameters	PSK Secret	*****	
transform-set	Define transform and settings	Local ID Type	Default	2
outer(config) #cr	pto ipsec transform-set Trans ?	cocar to type	Delauit	
ah-md5-hmac Al	H-HMAC-MD5 transform	Remote ID Type	Default	
	H-HMAC-SHA transform			าด
	SP transform using 3DES(EDE) cipher (168 bits)	IKE Lifetime	86400	
	SP transform using AES cipher			
	SP transform using DES cipher (56 bits)	→ SA Settings		
	SP transform using HMAC-MD5 auth SP transform using HMAC-SHA auth	Encrypt Algorithm	3DES 1	2
	/pto ipsec transform-set Trans esp-3des esp-md5-hmac	and the second se		
ouver (contrag) yes,	pro three organization and trains each ones each man inner	Authentication Algorithm	MD5	/
	SA Setting in Client must be	e consistent with server.		
	access-list extended vpn	PFS Group	MODP(1024)	2
	nacl) #permit ip 10.0.0.0 0.0.0.255 192.168.1.0 0.0.0	.255 SA Lifetime	28800	0
uter(config-ext-	nacl) ‡exit	SA Liteunie		
		DPD Interval	60	0
uter(config)#cry	pto map cry-map 10 ipsec-isakmp			
	rypto map will remain disabled until a peer	DPD Failures	180	0
	d access list have been configured.			
	to-map) #match address vpn	Advanced Settings		
	to-map) #set transform-set Trans	Enable Compression	OFF	
uter(config-cryp uter(config-cryp	to-map)#set peer 202.100.1.1	chable compression	Un	
ater (config=cryp	to-map/#exit			

Router(config)#interface fastEthernet 0/0 Router(config-if)#ip address 58.1.1.1 255.255.255.0 Router(config-if)#cr Router(config-if)#crypto map cry-map *Jan 3 07:16:26.785: %CRYPTO-6-ISAKMP_ON_OFF: ISAKMP is ON

RT_UG_R5020_v.1.0.0



5.2.2 OpenVPN

OpenVPN supports both client and P2P (peer-to-peer) modes. Here, the client is used as an example. The sample topology is shown below:



OpenVPN_Server:

Generate relevant OpenVPN certificate on the server side firstly, and refer to the following commands to configuration the Server: local 202.96.1.100 mode server port 1194 proto udp dev tun tun-mtu 1500 fragment 1500 ca ca.crt cert Server01.crt key Server01.key dh dh1024.pem server 10.8.0.0 255.255.255.0 ifconfig-pool-persist ipp.txt push "route 192.168.3.0 255.255.255.0" client-config-dir ccd route 192.168.1.0 255.255.255.0 keepalive 10 120 cipher BF-CBC comp-lzo max-clients 100 persist-key persist-tun status openvpn-status.log

verB 3


Note: For more configuration details, please contact your technical support engineer.

OpenVPN_Client

Click VPN > OpenVPN > OpenVPN as below.

OpenVPN Status		Status		x509			
∧ Tunnel S	ettings						
Index I	Enable	Description	Mode	Protocol	Server Address	Interface Type	+

Click + to configure the Client01 as below.

∧ General Settings	
Index	1
Enable	ON OFF
Description	Client01
Mode	Client
Protocol	UDP
Server Address	202.96.1.100
Server Port	1194
Interface Type	TUN
Authentication Type	X509CA V 🤇
Encrypt Algorithm	BF
Renegotiation Interval	86400
Keepalive Interval	20
Keepalive Timeout	120 🧿
Private Key Password	•••••
Enable Compression	ON DEF
Enable NAT	ON DEE
Verbose Level	3 7
Advanced Settings	
Enable HMAC Firewall	ON OFF
Enable PKCS#12	OFF
Enable nsCertType	OFF
Expert Options	fragment 1500

When finished, click **Submit > Save & Apply** for the configuration to take effect.



5.2.3 GRE VPN

The configuration of two points is as follows.



GRE-1:

The window is displayed as below by clicking **VPN > GRE > GRE**.

GRE		Status	
∧ Tunnel	Settings	1 · · · · · · · · · · · · · · · · · · ·	
Index	Enable	Description Remote IP Address	+

Click + button and set the parameters of GRE-1 as below.

∧ Tunnel Settings	
Index	1
Enable	ON OFF
Description	GRE-1
Remote IP Address	59.1.1.1
Local Virtual IP Address	10.8.0.1
Remote Virtual IP Address	10.8.0.2
Enable Default Route	ON OFF
Enable NAT	ON OFF
Secrets	•••••

When finished, click **Submit > Save & Apply** for the configuration to take effect.



GRE-2:

Click + button and set the parameters of GRE-1 as below.

GRE	
∧ Tunnel Settings	
Index	1
Enable	ON OFF
Description	
Remote IP Address	58.1.1.1
Local Virtual IP Address	[10.8.0.2
Local Virtual Netmask	255.255.255.0
Remote Virtual IP Address	10.8.0.1
Enable Default Route	ON OFF
Enable NAT	ON OFF
Secrets	•••••

When finished, click **Submit > Save & Apply** for the configuration to take effect.

The comparison between GRE-1 and GRE-2 is as below.

GRE-1		GRE-2	
 Tunnel Settings 		∧ Tunnel Settings	
Index	1	Index	1
Enable	ON OFF	Enable	ON OFF
Description	GRE-1	Description	GRE-2
Remote IP Address	59.1.1.1 GRE-1 pu	Remote IP Address	GRE-2 public IP
Local Virtual IP Address	10.8.0.1 GRE-1 tur	nel IP Local Virtual IP Address	GRE-2 tunnel IP
Remote Virtual IP Address	10.8.0.2 GRE-2 tur	nel IP Remote Virtual IP Address	GRE-1 tunnel IP
Enable Default Route	ON OFF	Enable Default Route	OFF
Enable NAT	or off set the same secret	as GRE-2 Enable NAT	set the same secret as GRE-1
Secrets	•••••	Secrets	•••••



Chapter 6 Introductions for CLI

6.1 What Is CLI

The Command Line Interface (CLI) is a set of software interfaces that provide another way to configure device parameters. Users can connect to the router through SSH or telnet to configure CLI commands. After establishing a Telnet or SSH connection with the router, enter the login account and password (default admin/admin) to enter the router's configuration mode, as shown below.

```
router login: admin
Password:
#
  1
                   Comments
  add
                   Add a list entry of configuration
                   Clear statistics
  clear
  config
                   Configuration operation
                   Output debug information to the console
  debug
                   Delete a list entry of configuration
Set the level state of the do
  del
  do
  exit
                   Exit from the CLI
  help Display an overview of the CLI syntax
ovpn_cert_get Download OpenVPN certificate file via http or ftp
                   Send messages to network hosts
  ping
                   Halt and perform a cold restart
  reboot
                   Set system configuration
  set
  show
                   Show system configuration
                   Show running system information
  status
  tftpupdate
                   Update firmware or configuration file using tftp
                   Print the route packets trace to network host
  traceroute
                   Trigger action
Update firmware via http or ftp
  trigger
  ur lupdate
  ver
                   Show version of firmware
#
```

```
Route login:
```

Router login: admin

```
Password: admin
```

#

CLI commands:

#? (*Note*: the '?' won't display on the page.)

#

!	Comments
add	Add a list entry of configuration
clear	Clear statistics
config	Configuration operation
debug	Output debug information to the console
del	Delete a list entry of configuration
do	Set the level state of the do
exit	Exit from the CLI



help	Display an overview of the CLI syntax
ovpn_cert_get	Download OpenVPN certificate file via http or ftp
ping	Send messages to network hosts
reboot	Halt and perform a cold restart
set	Set system configuration
show	Show system configuration
status	Show running system information
tftpupdate	Update firmware or configuration file using tftp
traceroute	Print the route packets trace to network host
trigger	Trigger action
urlupdate	Update firmware via http or ftp
ver	Show version of firmware

6.2 How to Configure the CLI

The following list is a description of the help information commands and the error commands encountered during configuration.

Commands /tips	Description	
?	Typing a question mark "?" will show you the help information.	
	Example:	
	<pre># config (tick '?')</pre>	
	config Configuration operation	
	<pre># config (tick space key+ +'?')</pre>	
	commit Save the configuration changes and take effect	
	changed configuration	
	save_and_apply Save the configuration changes and take effect	
	changed configuration	
	loaddefault Restore Factory Configuration	
Ctrl+c	Press these two keys at the same time, except its "copy" function but also	
	can be used for "break" out of the setting program.	
Syntax error: The command is not completed	Command is not completed.	
Tick space key+ Tab key	It can help you finish you command.	
	Example:	
	# config (tick Enter key)	
	Syntax error: The command is not completed	
	# config (tick space key+ Tab key)	
	commit save_and_apply loaddefault	
#config commit	When your setting finished, you should enter those commands to make	



# config save_and_apply	your setting take effect on the device.
	Note: Commit and save_and_apply plays the same role.

6.3 Commands Reference

Commands	Syntax	Description
Debug	Debug parameters	Turn on or turn off debug function
Show	Show parameters	Show current configuration of each function
Set	Set parameters	All the function parameters are set by commands set and add, the
Add	Add parameters	difference is that set is for the single parameter and add is for the list
		parameter

Note: More detail about CLI command, please refer to "Command Line Interface Guide".

6.4 Quick Start with Configuration Examples

The best and quickest way to master CLI is firstly to view all features from the webpage and then read all CLI commands at a time, finally learn to configure it with some reference examples.

Example 1: Show current version

```
# status system
firmware_version = 3.1.0
firmware_version_full = "3.1.0 (Rev 3527)"
kernel_version = 3.18.92
device_model = R5020-5G
serial_number = 20113056894526
uptime = "0 days, 00:37:26"
system_time = "Sun Jan 1 00:37:09 2017 (NTP not updated)"
ram_usage = "386M Free/448M Total"
#
```

Example 2: Update firmware via tftp



Checking 100%	
Decrypting 100%	
Flashing 100%	
Verifying 100%	
Verfify Success	
upgrade success	//update success
<pre># config save_and_apply</pre>	
ОК	//save and apply current configuration, make you configuration effect

Example 3: Set link-manager

# set	
ai	AI
cellular	Cellular
ddns	DDNS
dido	DIDO
email	Email
ethernet	Ethernet
event	Event Management
firewall	Firewall
gre	GRE
ip_passthrough	IP Passthrough
ipsec	IPSec
lan	Local Area Network
link_manager	Link Manager
ntp	NTP
openvpn	OpenVPN
reboot	Automatic Reboot
route	Route
serial_port	Serial Port
sms	SMS
ssh	SSH
syslog	Syslog
system	System
usb	USB
user_manageme	ent User Management
web_server	Web Server
wifi	WiFi AP
# cot link manager	
# set link_manager	
primary_link	Primary Link
backup_link	Backup Link
backup_mode	Backup Mode Revert Interval
revert_interval	
emergency_rebo	
link	Link Settings



	nt primary_link (space+?)	
•	(wwan1/wwan2/wan/wlan)	
# set link_management primary_link wwan1		//select "wwan1" as primary_link
OK		//setting succeed
set link_manager link		
type	Type	
desc	Description	
connection_type	Connection Type	
wwan	WWAN Settings	
static_addr	Static Address Settings	
pppoe	PPPoE Settings	
ping	Ping Settings	
mtu	MTU	
dns1_overrided	Overrided Primary DNS	
dns2_overrided	Overrided Secondary DNS	
<pre># set link_manager lin</pre>	ik 1 type wwan1	
ОК		
<pre># set link_manager lin</pre>	ık 1 wwan	
auto_apn	Automatic APN Selection	
apn	APN	
username	Username	
password	Password	
dialup_numBer	Dialup NumBer	
auth_type	Authentication Type	
aggressive_reset	Aggressive Reset	
switch_By_data_all	owance Switch SIM By Data Allowance	
data_allowance	Data Allowance	
Billing_day	Billing Day	
# set link_manager lir	nk 1 wwan switch_By_data_allowance true	e
ОК		
#		
# set link_manager lir	ık 1 wwan data_allowance 100	<pre>//open cellular switch_by_data_traffic</pre>
OK		//setting succeed
# set link_manager link 1 wwan billing_day 1		//setting specifies the day of month for billing
ОК		// setting succeed
<pre># config save_and_ap</pre>	ply	
ОК		rrent configuration, make you configuration effect

Example 4: Set LAN IP address

<pre># set Ethernet port_setting 2 port_assignment lan0</pre>	<pre>// Set Table 2 (eth1) to lan0</pre>
OK	
# config save_and_apply	<pre>// Make the configuration take effect</pre>
ОК	



Example 5: Set LAN IP address

```
# show lan all
network {
id = 1
interface = lan0
ip = 192.168.0.1
netmask = 255.255.255.0
mtu = 1500
dhcp {
          umber = true
         mode = server
         relay_server = ""
         pool_start = 192.168.0.2
         pool_end = 192.168.0.100
         netmask = 255.255.255.0
         gateway = ""
         primary_dns = ""
         secondary_dns = ""
         wins_server = ""
         lease_time = 120
         expert_options = ""
          umbe_enaBle = false
}
vlan_id = 0
}
multi_ip {
id = 1
interface = lan0
ip = 172.16.24.24
netmask = 255.255.0.0
}
#
# set lan
  network
                  Network Settings
  multi_ip
             Multiple IP Address Settings
                  VLAN
  vlan
# set lan network 1(space+?)
  interface Interface
                  IP Address
  ip
  netmask
             Netmask
  mtu
             MTU
  dhcp
             DHCP Settings
# set lan network 1 interface lan0
OK
```



```
# set lan network 1 ip 172.16.24.24 //set IP address for lan
OK //setting succeed
# set lan network 1 netmask 255.255.0.0
OK
#
...
# config save_and_apply
OK // save and apply current configuration, make you configuration effect
```

Example 6: CLI for Setting Cellular

```
}
# show cellular all
sim {
    id = 1
    card = sim1
    phone_number = ""
    pin_code = ""
    extra_at_cmd = ""
    telnet_port = 0
    network_type = auto
    band_select_type = all
    band_settings {
         gsm_850 = false
         gsm_900 = false
         gsm_1800 = false
         gsm_1900 = false
         wcdma_800 = false
         wcdma_850 = false
         wcdma 900 = false
         wcdma_1900 = false
         wcdma_2100 = false
         wcdma_1700 = false
         wcdma_band19 = false
         lte_band1 = false
         lte_band2 = false
         lte_band3 = false
         lte_band4 = false
         lte_band5 = false
         lte_band7 = false
         lte_band8 = false
         lte_band11 = false
         Ite_band12 = false
         lte_band13 = false
         lte_band14 = false
```



Ite band17 = false lte_band18 = false Ite band19 = false lte_band20 = false lte_band21 = false lte_band24 = false lte_band25 = false Ite band26 = false lte_band28 = false Ite_band30 = false lte_band31 = false Ite_band34 = false Ite band37 = false lte_band38 = false lte_band39 = false lte_band40 = false Ite band41 = false nsa_nr5g_band38 = false nsa_nr5g_band41 = false nsa_nr5g_band77 = false nsa_nr5g_band78 = false nsa_nr5g_band79 = false nr5g_band1 = false nr5g band2 = false nr5g_band3 = false nr5g_band5 = false nr5g_band7 = false nr5g_band8 = false nr5g band12 = false nr5g_band20 = false nr5g_band28 = false nr5g_band38 = false nr5g band40 = false nr5g_band41 = false nr5g_band66 = false nr5g_band71 = false nr5g_band77 = false nr5g_band78 = false nr5g_band79 = false telit_band_settings { gsm_band = 900_and_1800 wcdma_band = 1900 debug enable = true verbose_debug_enable = false

}

}



```
creg_timeout = 0
}
sim {
    id = 2
    card = sim2
    phone number = ""
    pin_code = ""
    extra at cmd = ""
    telnet_port = 0
    network_type = auto
    band_select_type = all
    band_settings {
         gsm_850 = false
         gsm_900 = false
         gsm_1800 = false
         gsm_1900 = false
         wcdma_800 = false
         wcdma_850 = false
         wcdma_900 = false
         wcdma_1900 = false
         wcdma_2100 = false
         wcdma_1700 = false
         wcdma_band19 = false
         Ite band1 = false
         lte_band2 = false
         lte_band3 = false
         lte_band4 = false
         lte_band5 = false
         Ite band7 = false
         lte_band8 = false
         lte_band11 = false
         lte_band12 = false
         Ite band13 = false
         lte_band14 = false
         lte_band17 = false
         lte_band18 = false
         lte_band19 = false
         Ite band20 = false
         lte_band21 = false
         Ite band24 = false
         lte_band25 = false
         Ite_band26 = false
         lte_band28 = false
         Ite_band30 = false
         Ite band31 = false
         Ite_band34 = false
```



Ite band37 = false Ite_band38 = false Ite band39 = false lte_band40 = false lte_band41 = false nsa_nr5g_band38 = false nsa_nr5g_band41 = false nsa_nr5g_band77 = false nsa_nr5g_band78 = false nsa_nr5g_band79 = false nr5g_band1 = false nr5g_band2 = false nr5g_band3 = false nr5g_band5 = false nr5g_band7 = false nr5g_band8 = false nr5g_band12 = false nr5g_band20 = false nr5g band28 = false nr5g_band38 = false nr5g_band40 = false nr5g_band41 = false nr5g_band66 = false nr5g_band71 = false nr5g_band77 = false nr5g_band78 = false nr5g_band79 = false } telit_band_settings { gsm_band = 900_and_1800 wcdma_band = 1900 } debug_enable = true verbose_debug_enable = false creg_timeout = 0 AI cellular Cellular ddns DDNS dido DIDO email Email ethernet Ethernet

Event Management

Firewall

} # set

ai

event

firewall



gre	GRE
ip_passthrough	IP Passthrough
ipsec	IPSec
lan	Local Area Network
link_manager	Link Manager
ntp	NTP
openvpn	OpenVPN
reboot	Automatic Reboot
route	Route
serial_port	Serial Port
sms	SMS
ssh	SSH
syslog	Syslog
system	System
usb	USB
user_manageme	nt User Management
web_server	Web Server
wifi	WiFi AP
# set cellular(space-	+?)
sim SIM Setti	ings
# set cellular sim(sp	pace+?)
Integer Index	< (12)
set cellular sim 1(space+?)
card	SIM Card
phone_number	Phone Number
pin_code	PIN Code
extra_at_cmd	Extra AT Cmd
telnet_port	Telnet Port
network_type	Network Type
band_select_type	e Band Select Type
band_settings	Band Settings
telit_band_settin	igs Band Settings
debug_enable	Debug Enable
verbose_debug_	enable Verbose Debug Enable# set cellular sim 1 phone_numBer 18620435279
ОК	
 # config save_and_a	apply
	abbit
ОК	
OK # config save_and_a	apply



Glossary

Abbr.	Description
AC	Alternating Current
APN	Access Point Name of GPRS Service Provider Network
ASCII	American Standard Code for Information Interchange
CE	Conformité Européene (European Conformity)
СНАР	Challenge Handshake Authentication Protocol
CLI	Command Line Interface for batch scripting
CSD	Circuit Switched Data
CTS	Clear to Send
dB	Decibel
dBi	Decibel Relative to an Isotropic radiator
DC	Direct Current
DCD	Data Carrier Detect
DCE	Data Communication Equipment (typically modems)
DCS 1800	Digital Cellular System, also referred to as PCN
DI	Digital Input
DO	Digital Output
DSR	Data Set Ready
DTE	Data Terminal Equipment
DTMF	Dual Tone Multi-frequency
DTR	Data Terminal Ready
EDGE	Enhanced Data rates for Global Evolution of GSM and IS-136
EMC	Electromagnetic Compatibility
EMI	Electro-Magnetic Interference
ESD	Electrostatic Discharges
ETSI	European Telecommunications Standards Institute
FDD LTE	Frequency Division Duplexing Long Term Evolution
GND	Ground
GPRS	General Packet Radio Service
GRE	generic route encapsulation
GSM	Global System for Mobile Communications
HSPA	High Speed Packet Access
ID	identification data
IMEI	International Mobile Equipment Identification
IP	Internet Protocol
IPsec	Internet Protocol Security
kbps	kbits per second
L2TP	Layer 2 Tunneling Protocol



Abbr.	Description
LAN	local area network
LED	Light Emitting Diode
M2M	Machine to Machine
MAX	Maximum
Min	Minimum
MO	Mobile Originated
MS	Mobile Station
MT	Mobile Terminated
OpenVPN	Open Virtual Private Network
РАР	Password Authentication Protocol
PC	Personal Computer
PCN	Personal Communications Network, also referred to as DCS 1800
PCS	Personal Communication System, also referred to as GSM 1900
PDU	Protocol Data Unit
PIN	Personal Identity Number
PLCs	Program Logic Control System
РРР	Point-to-point Protocol
РРТР	Point to Point Tunneling Protocol
PSU	Power Supply Unit
PUK	Personal Unblocking Key
R&TTE	Radio and Telecommunication Terminal Equipment
RF	Radio Frequency
RTS	Request to Send
RTU	Remote Terminal Unit
Rx	Receive Direction
SDK	Software Development Kit
SIM	subscriber identification module
SMA antenna	Stubby antenna or Magnet antenna
SMS	Short Message Service
SNMP	Simple Network Management Protocol
TCP/IP	Transmission Control Protocol / Internet Protocol
TE	Terminal Equipment, also referred to as DTE
Тх	Transmit Direction
UART	Universal Asynchronous Receiver-transmitter
UMTS	Universal Mobile Telecommunications System
USB	Universal Serial Bus
USSD	Unstructured Supplementary Service Data
VDC	Volts Direct Current
VLAN	Virtual Local Area Network
VPN	Virtual Private Network
VSWR	Voltage Stationary Wave Ratio



Abbr.	Description
WAN	Wide Area Network
VSWR	Voltage Stationary Wave Ratio
WAN	Wide Area Network

Guangzhou Robustel LTD

Address:	3rd Floor, Building F, Kehui Park, No.95 Daguan Road,
	Guangzhou, China 510660
Tel:	86-20-29019902
Email:	info@robustel.com